



HIGHlite 4K Series

High Brightness Digital Video Projector

- ▶ INSTALLATION AND QUICK-START GUIDE
 - ▶ CONNECTION GUIDE
 - ▶ OPERATING GUIDE
 - ▶ REFERENCE GUIDE



About This Document

Follow the instructions in this manual carefully to ensure safe and long-lasting use of the projector.

Symbols used in this manual

Many pages in this document have a dedicated area for notes. The information in that area is accompanied by the following symbols:



WARNING: this symbol indicates that there is a danger of physical injury to yourself and/or damage to the equipment unless the instructions are closely followed.



ELECTRICAL WARNING: this symbol indicates that there is a danger of electrical shock unless the instructions are closely followed.



LASER WARNING: this symbol indicates that there is a potential hazard of eye exposure to laser radiation unless the instructions are closely followed.



NOTE: this symbol indicates that there is some important information that you should read.

Product revision

Because we at Digital Projection continually strive to improve our products, we may change specifications and designs, and add new features without prior notice.


Legal notice


Trademarks and trade names mentioned in this document remain the property of their respective owners. Digital Projection disclaims any proprietary interest in trademarks and trade names other than its own.

Notes

Laser Information

RISK GROUP 2	
CAUTION Possibly hazardous optical radiation emitted from this product. Do not stare at operating lamp. May be harmful to the eyes.	ATTENTION Ce produit peut émettre des rayonnements optiques dangereux. Ne pas fixer la lampe en fonctionnement. Peut être nocif pour les yeux.



 **Caution - use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.**

Notes

Introduction

Congratulations on your purchase of this Digital Projection product.

Your projector has the following key features:

- 4K-UHD projector.
- HDBaseT® for transmission of uncompressed High Definition Video up to 100 m from the source.
- 3G-SDI with loop-through.
- Edge Blend with black-level correction.
- Blanking control for custom input window sizing.
- Cornerstone, Vertical & Horizontal Keystone, Pincushion & Barrel, and Image Rotation.
- Control via LAN and RS232.
- Motorised lens mount.
- Separate control of screen and source aspect ratio.
- Non-linear warp for irregular projection surfaces.

A serial number is located on the side of the projector. Record it here:

Notes

CONTENTS

INSTALLATION AND QUICK-START GUIDE	1	CONNECTION GUIDE	19
WHAT'S IN THE BOX?	3	SIGNAL INPUTS	21
CONNECTING THE POWER SUPPLY	4	Digital inputs and outputs.....	21
Voltage selection	4	Using HDMI/DisplayPort switchers with the projector	22
PROJECTOR OVERVIEW	5	CONTROL CONNECTIONS	23
Front and rear views	5	LAN connection examples	24
CONTROL PANEL	6	RS232 connection example	25
REMOTE CONTROL	7	OPERATING GUIDE	27
Infrared reception	10	USING THE MENUS	29
POSITIONING THE SCREEN AND PROJECTOR	11	Opening the OSD.....	29
Roll and pitch	12	Opening a menu.....	29
CHANGING THE LENS	13	Exiting menus and closing the OSD.....	29
The lens hood	13	Inside a menu.....	30
Inserting a new lens	14	<i>Accessing sub-menus</i>	30
Removing the lens	15		
OPERATING THE PROJECTOR	16		
Switching the projector on.....	16		
Switching the projector off.....	16		
Selecting an input signal	17		
Selecting a test pattern	17		
Adjusting the lens.....	18		
Adjusting the image.....	18		

CONTENTS (continued)

Executing commands..... 30

Editing projector settings..... 31

Using a slider to set a value..... 31

Editing numeric values 31

USING THE PROJECTOR..... 32

 Main menu 32

 Lens menu 33

Lens Control..... 33

Lens Memory..... 34

 Image menu 35

 Color menu..... 37

Color Space 37

Color Mode 38

 Geometry menu 43

Aspect Ratio..... 43

Digital Zoom 45

Overscan..... 46

Blanking 47

Keystone 48

4 Corners 50

Rotation 51

Pincushion / Barrel..... 52

Custom Warp 53

Arc..... 54

 Edge Blend menu..... 55

Blend Width..... 56

Black Level Uplift 57

 Laser menu 58

Setup menu..... 59

ColorMax..... 62

Power On/Off..... 63

Clock Adjust 64

OSD Settings..... 65

Memory..... 65

Network menu 66

PIP menu 67

Information menu 68

Signal Format 68

System Status 69

Thermal Status..... 69

Factory Reset 70

SERVED WEB PAGES..... 71

REFERENCE GUIDE.....81

CHOOSING A LENS 83

 Basic calculation 84

 Basic calculation example..... 85

 Full lens calculation..... 86

Introducing TRC 86

Calculating TRC 87

Calculating the throw ratio with TRC 88

 Full lens calculation example 89

SCREEN REQUIREMENTS 90

 Fitting the image to the display 90

CONTENTS (continued)

4K-UHD images displayed full width 90

4K-UHD images displayed with a height of 2160 pixels..... 91

4K-UHD images displayed full height 92

Diagonal screen sizes 93

POSITIONING THE IMAGE 94

ASPECT RATIOS EXPLAINED..... 96

 Aspect ratio examples..... 97

APPENDIX A: LENS PART NUMBERS..... 99

APPENDIX B: SUPPORTED SIGNAL INPUT MODES 100

 2D formats..... 100

 SDI Format..... 102

APPENDIX C: WIRING DETAILS 104

 Signal inputs and outputs..... 104

HDMI 1 and 2 104

DisplayPort 105

3G-SDI In, 3G-SDI Out..... 106

 Control connections 107

LAN 107


RS232 107

Trigger 1 & Trigger 2..... 108

IR input 108

APPENDIX D: GLOSSARY OF TERMS 109

This page is intentionally left blank.





HIGHlite Laser 4K Series

High Brightness Digital Video Projector


▶ INSTALLATION AND QUICK-START GUIDE




IN THIS GUIDE

- What's In The Box?**..... 3
- Connecting The Power Supply**..... 4
 - Voltage selection.....4
- Projector Overview**..... 5
 - Front and rear views5
- Control Panel** 6
- Remote Control**..... 7
 - Infrared reception.....10
- Positioning The Screen And Projector**..... 11
 - Roll and pitch12
- Changing The Lens**..... 13
 - The lens hood.....13
 - Inserting a new lens14
 - Removing the lens15
- Operating The Projector** 16
 - Switching the projector on.....16
 - Switching the projector off.....16
 - Selecting an input signal.....17
 - Selecting a test pattern.....17
 - Adjusting the lens18
 - Adjusting the image.....18


What's In The Box?




Remote control




2x AAA batteries




Projector




User Manual on disc




Important Information




remote control cable




HDMI cable




Power cable, United Kingdom



Power cable, Europe










Power cable, North America



Power cable, China


Notes

-  Make sure your box contains everything listed. If any pieces are missing, contact your dealer.
-  Only one remote will be supplied with the projector. For more information, see [Remote Control](#) further in this guide.
-  You should save the original box and packing materials, in case you ever need to ship your projector.
-  The projector is shipped without a lens.
-  **Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.**
-  For further information about using the right lens and hood, see [The lens hood](#) further in this guide.
-  Only one power cable - dependent on the destination territory - will be supplied with the projector.





Connecting The Power Supply

Lift the cable lock up, push the mains connector in firmly and push the lock down to secure the cable.

- 1 AC mains inlet with cable lock





Notes

-  Use only the power cable provided.
-  Ensure that the power outlet includes a ground connection as this equipment **MUST** be earthed.
-  Handle the power cable carefully and avoid sharp bends. Do not use a damaged power cable.
-  When operating on 110V Light output power is reduced by approx 30%.

Voltage selection



The VOLTAGE SELECT switch must be set to match the power supply you are using:

Voltage of power supply used	Position of VOLTAGE SELECT switch
AC100V outlet	200 240V~  110 130V~
AC200V (single phase) outlet	200 240V~  110 130V~

Projector Overview

Front and rear views

- 1 Connection panel
- 2 Air outlet
- 3 Control panel
- 4 Power switch and power connection
- 5 Lens hood
- 6 Front infrared window
- 7 Air inlet
- 8 Air outlet
- 9 Rear infrared window
- 10 Adjustable feet



Notes














Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.



For further information about using the right lens and hood, see [The lens hood](#) further in this guide.

Control Panel

- 1 ON indicator (blue)**
Behavior
 Off  The projector is switched off.
 On  The projector is switched ON.
 Flashing  The projector is warming up or cooling down.
- 2 ERROR indicator (red)**
Behavior
 Flash once, then pause  Laser failure.
 Flash twice, then pause  Cover open.
 Flash three times, then pause  Fan failure.
 Flash four times, then pause  Over temperature.
 On  System error.
- 3 STANDBY indicator (green)**
Behavior
 On  The projector is in STANDBY mode.
 Flashing  The projector is in STANDBY mode.
 It can be switched on with a network command.
- 4 MENU button**
 Access the projector OSD (on-screen display).
- 5 Navigation (arrow buttons and ENTER)**
 Navigate the OSD and edit settings with the arrows, confirm choice with **ENTER**.
- 6 INPUT button**
 Select input source.
- 7 Focus IN / OUT**
 Adjust focus.
- 8 Zoom IN / OUT**
 Adjust zoom.
- 9 Shutter CLOSE / OPEN**
 Open and close the shutter.
- 10 POWER button**
 Switch the projector on and off (in STANDBY mode)
- 11 EXIT button**
 Close the OSD.
- 12 SHIFT button**
 Press and hold this button, then press the arrow buttons to move the lens.




Notes


Remote Control

- 1 Power ON / OFF**
Turns power on and off.
- 2 Pic Mute OPEN / CLOSE**
Shows and hides the projected image.
When CLOSE is pressed, the light source switches off completely and the screen becomes black.
- 2 OSD ON / OFF**
Enable and disable screen timeout messages and control whether to show the OSD during projection.
- 4 MENU**
Access the OSD. If the OSD is open, press this button to go back to the previous menu.
- 5 Navigation (arrows and OK)**
Navigate through the menus with the arrows, confirm your choice with **OK**.
In lens adjustment modes, the arrows are used to move, zoom or focus the lens. See **11** below.
In lens adjustment modes, or when the OSD is not showing, the **OK** button switches between modes: **Shift Adjustment** and **Zoom / Focus Adjustment**.
- 6 EXIT**
Go up one level in the OSD. When the top level is reached, press to close the OSD.
- 7 FREEZE**
Freeze the current frame.
- 8 DEFAULT**
When editing a parameter, press this button to restore the default value.
- 9 INFO**
Access information about the projector.
- 10 RE-SYNC**
Re-synchronise with the current input signal.


continues on next page...



Notes

 This projector does not use the following options on the remote:
HDMI 3 and 4, DVI, VGA, COMP 1, COMP 2, 3D, EYE and SWAP

- 11** **LENS adjustment**
FOCUS IN / OUT: adjust focus.
SHIFT: press and hold this button, then use the Navigation arrow buttons to move the lens.
ZOOM IN / OUT: adjust zoom.
- 12** **USER PRESET A, B, C, D**
 Load user presets.
- 13** **ALT**
 Press and hold this button to access alternative functions for all buttons with a green label.
- 14** **DVI / DisplayPort2 / numeric input 3**
 There is no DVI input on this projector.
 There is no DisplayPort2 input on this projector.
- 15** **HDMI 2 / HDMI 4 / numeric input 2**
 Select the HDMI 2 input.
 There is no HDMI 4 input on this projector.
- 16** **HDMI 1 / HDMI 3 / numeric input 1**
 Select the HDMI 1 input.
 There is no HDMI 3 input on this projector.
- 17** **TEST / SWAP / numeric input 0**
 Show a test pattern. Press again to show the next test pattern:
...Off, White, Black, Red, Green, Blue, CheckerBoard, CrossHatch, V Burst, H Burst, ColorBar, Screen Layout...
 Use with **ALT** to switch between the **Main** and **Sub PIP** display.



Remote control



Notes

For further information about user presets, see [Memory](#) in the **Operating Guide**.

This projector does not use the following options on the remote:
 Inputs HDMI 3 and 4, DVI, VGA, COMP 1, COMP 2, 3D, EYE and SWAP

continues on next page...

- 17 DISPLAYPORT / R / numeric input 4**
Select DisplayPort input.
Use with **ALT** to turn the **Red channel** of the display on and off.
- 18 HD-T / G / numeric input 5**
Select the HDBaseT input.
Use with **ALT** to turn the **Green channel** of the display on and off.
- 19 3GSDI / B / numeric input 6**
Select the 3G-SDI input.
Use with **ALT** to turn the **Blue channel** of the display on and off.
- 20 VGA / 3D / numeric input 7**
There is no VGA input on this projector.
There is no 3D function on this projector.
- 21 COMP1 / EYE / numeric input 8**
There is no Component 1 input on this projector.
There is no EYE swap for 3D function on this projector.
- 22 COMP2 / PIP / numeric input 9**
There is no Component 2 input on this projector.
Use with **ALT** to switch on **Picture In Picture (PIP)** mode.
- 23 ADDR / ALL (with red indicator at the top)**
Assign and unassign an IR remote address.
To assign an address:
 1. Press and hold this button until the indicator starts flashing.
 2. Release this button and while the indicator is still flashing, enter a two-digit address using the numeric input buttons. The indicator will flash three times quickly to confirm the change.**To unassign an address and return to the default address 00,**
 - Press and hold **ALT** and this button simultaneously until the indicator flashes to confirm the change.



Notes


This projector does not use the following options on the remote:

Inputs HDMI 3 and 4, DVI, VGA, COMP 1, COMP 2, 3D, EYE and SWAP

Infrared reception

The projector has infrared sensors at the front and back.

The angle of acceptance is 40°. Make sure that the remote control is within the angle of acceptance when trying to control the projector.




Notes

Positioning The Screen And Projector


1. Install the screen, ensuring that it is in the best position for viewing by your audience.
2. Mount the projector, ensuring that it is at a suitable distance from the screen for the image to fill the screen. Set the adjustable feet so that the projector is level, and perpendicular to the screen.


The drawing below shows the positions of the feet for table mounting, and the fixing holes for ceiling mounting.


- 1** Four adjustable feet
- 2** Six M6 holes for ceiling mount
The screws should not penetrate more than 15 mm into the body of the projector.



Notes

 **Always allow the projector to cool for 5 minutes before disconnecting the power or moving the projector.**


 **Ensure that there is at least 50 cm (20 in) of space between the ventilation outlets and any wall, and 30 cm (12 in) on all other sides.**

 **Do not stack more than 3 projectors.**

Roll and pitch

The projector can be operated in numerous positions.

It is not recommended to position the projector in portrait mode with inputs facing upward, as shown in the diagram.



- 1** Positions to avoid: inputs side up
- 2** Recommended positions

Notes


Changing The Lens

The lens hood

There are two types of lens hood, short and long.

The short lens hood is used with the following lenses:


Throw ratios	Part number
0.77 : 1 fixed lens	110-808
0.96 - 1.43 : 1 zoom lens	119-011
1.16 : 1 fixed lens	110-809
1.45 - 1.74 : 1 zoom lens	110-803
1.74 - 2.17 : 1 zoom lens	112-878
2.17 - 2.90 : 1 zoom lens	113-852
2.90 - 4.34 : 1 zoom lens	110-806



Projector with short lens hood fitted

The long lens hood must be used with the following long throw lens:

Throw ratios	Part number
4.34 - 6.76 : 1 zoom lens	110-807



Projector with long lens hood fitted

Notes



Before changing the lens, always make sure the projector is switched off and fully disconnected from its power supply.



When changing the lens, avoid using excessive force as this may damage the equipment.



Take care to preserve the original lens packaging and protective caps for future use.



Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.






The projector will not power on without the lens and lens hood fitted.

Inserting a new lens

1. Insert the lens into the lens aperture, making sure that the plug on the zoom drive mechanism lines up with socket on the right of the lens aperture.

2. Rotate the lens clockwise until it clicks into place.

3. Secure the lens hood to the front of the projector with the screws.



Notes



Before changing the lens, always make sure the projector is switched off and fully disconnected from its power supply.



When changing the lens, avoid using excessive force as this may damage the equipment.



Take care to preserve the original lens packaging and protective caps for future use.



Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.



The projector will not power on without the lens and lens hood fitted.


Removing the lens

1. Loosen the four screws securing the lens hood to the body of the projector. Remove the lens hood.


2. Push down the lens holder tab.


3. Rotate the lens anti-clockwise.


4. Pull the lens forward to remove it from the lens aperture.




Notes

-  Before changing the lens, always make sure the projector is switched off and fully disconnected from its power supply.

-  When changing the lens, avoid using excessive force as this may damage the equipment.

-  Take care to preserve the original lens packaging and protective caps for future use.

-  The projector will not power on without the lens and lens hood fitted.

Operating The Projector

Switching the projector on

1. Ensure a lens is fitted. Connect the power cable between the mains supply and the projector. (See **Connecting the power supply** above.) Switch on at the switch next to the power connector.
2. The **POWER** indicator lights red to signal that the projector is in STANDBY mode. Press one of the following buttons:
 - On the remote control, the **ON** button
 - On the projector control panel, the **POWER** button.

The fans begin working, then the **POWER** indicator begins flashing green. When the flashing stops, the **POWER** and **LIGHT** indicators both light steady green. The projector is switched on.

Switching the projector off

1. Press **OFF** on the remote control or **POWER** on the control panel, then press again to confirm your choice.

The **POWER** indicator on the control panel will start flashing amber, the system will go out and the cooling fans will run for a short time until the **POWER** indicator goes steady red to indicate that the projector has entered STANDBY mode.

2. If you need to switch the projector off completely, switch off at the mains power switch next to the power connector and then disconnect the power cable from the projector.

Notes



See also [Connecting The Power Supply](#) earlier in this guide.



The self-test is running when all the LEDs on the control panel are lit.



Use only the power cable provided.



Ensure that the power outlet includes a ground connection as this equipment MUST be earthed.



Handle the power cable carefully and avoid sharp bends. Do not use a damaged power cable.

Selecting an input signal

1. Connect one or more image sources to the projector.
2. Select the input you want to display:
 - Press one of the input buttons on the remote control.
 - Alternatively, open the On-screen display (OSD) by pressing **MENU**. Highlight **Input** from the main menu, press **ENTER/OK** and then select an input signal using the **UP ▲** and **DOWN ▼** arrow buttons. Press **ENTER/OK** to confirm your choice.

Selecting a test pattern

To display a test pattern:

- Press **TEST** on the remote control.
Change the test pattern using the **LEFT ◀** and **RIGHT ▶** arrow buttons. Test patterns are displayed in the following order:
White, Black, Red, Green, Blue, CheckerBoard, CrossHatch, V Burst, H Burst, ColorBar, Screen Layout, Off
- Alternatively, open the OSD by pressing **MENU**. Highlight **Test Patterns** from the main menu, then select a test pattern using the **LEFT** and **RIGHT** arrow buttons.

After the final test pattern, the projector exits test pattern mode and returns to the main image. To view test patterns again, you need to press **TEST** again. If you wish to exit the test patterns before you reach the final one,

- press **TEST** or **EXIT** at any time.

Notes



For full details of how to use the controls and the menu system, see the [Operating Guide](#).

Adjusting the lens

The lens can be adjusted using the **Lens** menu, or using the lens buttons on the remote control.

Lens menu

The **Lens** menu provides access to the **Lens Control** setting and the **Lens Center** command.

Lens Control allows **Zoom**, **Focus** and **Shift** adjustment using the arrow buttons. The setting operates in **Zoom/Focus Adjustment** and **Shift Adjustment** mode.

Press **ENTER/SELECT** to switch between the two modes.

Remote control

Use the remote control to adjust zoom, focus and shift directly, without opening a menu:

- **OK** enters lens control, then switches between **Zoom/Focus Adjustment** and **Shift Adjustment**.
- **EXIT** exits lens control and opens the **Lens** menu.
- **MENU** exits lens control and returns to the main image.
- The arrow buttons adjust zoom, focus and shift as indicated on the screen.

Adjusting the image

Orientation

- This can be set from the **Setup** menu.

Highlight **Orientation** and choose from **Front Tabletop**, **Front Ceiling**, **Rear Tabletop**, **Rear Ceiling** and **Auto-front**.

Keystone

- This can be set from the **Geometry** menu.

Picture

- Settings such as **Gamma**, **Brightness**, **Contrast**, **Saturation**, **Hue** and **Sharpness** can be set from the **Image** menu.

Notes



When adjusting focus and zoom, you may find it useful to display the **CrossHatch** test pattern: press **TEST** on the remote control and navigate through the list of patterns using the **LEFT** ◀ and **RIGHT** ▶ arrow buttons.



For full details of how to adjust the lens using the remote control, see [Remote Control](#) earlier in this guide.

Setup menu

Geometry menu

Image menu



HIGHlite Laser 4K Series

High Brightness Digital Video Projector

▶ CONNECTION GUIDE



IN THIS GUIDE


Signal Inputs..... 21
 Digital inputs and outputs21
 Using HDMI/DisplayPort switchers with the projector22

Control Connections 23
 LAN connection examples24
 RS232 connection example.....25




Signal Inputs

Digital inputs and outputs

- 1 HDBaseT**
Receives digital signal from HDBaseT-compliant devices with LAN connectivity.
- 2 Ethernet**
Provides LAN connectivity
- 3 3G-SDI in**
- 4 3G-SDI out**
Connect a 3G-SDI cable to distribute the 3G-SDI signal to another projector.
- 5 HDMI I**
HDMI 2.0 input supporting HDCP2.2. Connect an **HDMI** cable to the connector.
- 6 HDMI II**
HDMI 2.0 input supporting HDCP2.2. Connect an **HDMI** cable to the connector.
- 7 DisplayPort**
DisplayPort 1.2 input. Connect a DisplayPort cable to the connector.
Supports sources up to 4K-UHD resolution at 60 Hz.



Notes

-  For simultaneous HDBaseT and LAN connectivity, a third-party distribution product can be utilised to combine HDBaseT video stream with LAN connection for delivery to the projector.
-  For a complete listing of all supported signal input modes, see [Appendix C: Supported Signal Input Modes](#) in the Reference Guide.
-  For a complete listing of pin configurations for all signal and control connectors, see [Appendix E: Wiring Details](#) in the Reference Guide.

EDID on the HDMI, DisplayPort inputs

If you are using a computer graphics card or another source that obeys the EDID protocol, the source will automatically configure itself to suit the projector.


Otherwise refer to the documentation supplied with the source to manually set the resolution to the DMD™ resolution of the projector or the nearest suitable setting. Switch off the source, connect to the projector, then switch the source back on again.

Using HDMI/DisplayPort switchers with the projector

When using an HDMI/DisplayPort source switcher with the projector, it is important to set the switcher so that it passes the projector EDID through to the source devices. If this is not done, the projector may not be able to lock to the source or display the source correctly as its video output timings may not be compatible with those of the projector. Sometimes this is called transparent, pass-through or clone mode. See your switcher's manual for information on how to set this mode.

Additionally, sources which use HDCP encryption may not display properly when connected to the projector via a switcher. Refer to the switcher's manual for more information.

Notes



The EDIDs in the switcher should be the same as the one in the projector.

Control Connections

- 1 HDBaseT/LAN**

The projector's features can be controlled via a LAN connection, using Digital Projection's **Projector Controller** application or a terminal-emulation program.
- 2 Ethernet**


This dedicated LAN connection can be used if **HDBaseT/LAN** is already being used for HDBaseT signal input.
- 3 Trigger 1 & Trigger 2**

The Trigger outputs are activated by one of the three following conditions, as set in the **Setup** menu:

 - Screen trigger: can be connected to an electrically operated screen, automatically deploying the screen when the projector starts up, and retracting the screen when the projector shuts down.
 - Aspect ratio trigger: can be used to control screen shuttering for different aspect ratios.
 - RS232 trigger: can be used to control the screen or screen shuttering on receipt of an RS232 command
- 4 RS232**

 - All of the projector's features can be controlled via a serial connection, using commands described in the **Protocol Guide**.
 - Use a straight-through cable to connect directly to a computer.
- 5 Wired Remote**

The remote control can be connected using a standard 3.5 mm mini jack cable (tip-ring-sleeve, or TRS).




Control connections

Notes


- For a list of all commands used to control the projector via LAN, see the **Protocol Guide**.
- Only one remote connection (RS232 or LAN) should be used at any one time.
- With a LAN connection the projector can serve a web page offering status and projector controls.
- Projector Controller** is available for download, free of charge, from the Digital Projection website.


LAN connection examples

The projector's features can be controlled via a LAN connection, using Digital Projection's **Projector Controller** application or a terminal-emulation program.





Notes

 **Projector Controller** is available for download, free of charge, from the Digital Projection website.



RS232 connection example



Notes

This page is intentionally left blank.



HIGHlite Laser 4K Series

High Brightness Digital Video Projector

▶ OPERATING GUIDE



CONTENTS

USING THE MENUS.....29

OPENING THE OSD 29

OPENING A MENU 29

EXITING MENUS AND CLOSING THE OSD 29

INSIDE A MENU 30

 Accessing sub-menus 30

 Executing commands..... 30

EDITING PROJECTOR SETTINGS..... 31

 Using a slider to set a value 31

 Editing numeric values 31

USING THE PROJECTOR.....32

MAIN MENU 32

LENS MENU..... 33

 Lens Control..... 33

 Lens Memory 34

IMAGE MENU..... 35

COLOR MENU..... 37

 Color Space 37

 Color Mode..... 38

GEOMETRY MENU 43

 Aspect Ratio..... 43

 Digital Zoom 45

 Overscan..... 46

 Blanking 47

 Keystone 48

 4 Corners 50

 Rotation..... 51

 Pincushion / Barrel..... 52

 Custom Warp 53

 Arc..... 54

EDGE BLEND MENU..... 55

 Blend Width..... 56

 Black Level Uplift..... 57

LASER MENU 58

SETUP MENU 59

 ColorMax..... 62

 Power On/Off 63

 Clock Adjust 64

 OSD Settings 65

 Memory 65

NETWORK MENU 66

PIP MENU 67

INFORMATION MENU 68

 Signal Format..... 68

 System Status 69

 Thermal Status..... 69

 Factory Reset..... 70

SERVED WEB PAGES.....71

Using The Menus

Opening the OSD

Access the various menus using either the projector control panel or the remote control. On either device,

- press the **MENU** button.

The on-screen display (OSD) opens showing the list of available menus.

Opening a menu

Move up and down the list using the **UP** ▲ and **DOWN** ▼ arrow buttons.

To open a menu,

- press **ENTER** on the control panel or **OK** on the remote control.

This guide refers to the above two buttons as **ENTER/OK**.

Exiting menus and closing the OSD


To go back to the previous page,

- press **EXIT**.

When you reach the top level, pressing **EXIT** will close the OSD.

To close the OSD from any page,

- press **MENU**.





Projector control panel



Remote control

Notes



On-screen display (OSD): top level menus

Inside a menu

When you open a menu, the page consists of the following elements:

- Title bar at the top
Shows which menu you have accessed.
- Highlighted item
- Available and unavailable items
Unavailable items appear a pale gray color. Whether an item is available may depend on other settings.
- The text or symbol to the right of an item shows whether the item:
 - has a value that can be changed (the current value is shown)
 - opens a sub-menu (an arrow button ► is displayed)
 - executes a command (the space to the right of the item is blank).

Accessing sub-menus


Use the **UP ▲** and **DOWN ▼** arrow buttons to highlight the sub-menu, then press **ENTER/OK**.

Executing commands


If the item contains a command, highlighting it reveals an **OK** button.

Press **ENTER/OK** to execute the highlighted command.


You may be asked for confirmation. Use the **ENTER/OK** to confirm, or **EXIT** to cancel.



Inside a menu



Highlighted command



Confirmation dialog

Notes



The highlighted item has green background.

Editing projector settings

If the highlighted menu item contains a list of values to choose from, you can change the value by doing the following:

1. Highlight the menu item and press **ENTER/OK**.
2. In the list of values that opens, use the **UP ▲** and **DOWN ▼** arrow buttons to highlight a value, then press **ENTER/OK** again to select the highlighted value.

Using a slider to set a value

Some parameters open a slider. To set such a parameter:

1. Press the **LEFT ◀** or **RIGHT ▶** arrow button, or **ENTER/OK**. The arrow buttons will open the slider and adjust the value at the same time. **ENTER/OK** will open the slider without altering the initial value.
2. Use the **LEFT ◀** and **RIGHT ▶** arrow buttons to move the slider.
3. When ready, press **EXIT** to exit the slider and return to the menu, or press **MENU** to exit the slider without showing the menu again.

Editing numeric values

Some parameters take numeric values without using sliders - for example, color matching values or IP addresses.

1. Use the **UP ▲** and **DOWN ▼** arrow buttons to highlight the row containing the numeric field you wish to edit.
2. Press **ENTER/OK** to enter edit mode. A numeric field in edit mode is white text on blue background.
3. In edit mode:
 - Use the **UP ▲** arrow button to increase the numeric value.
 - Use the **DOWN ▼** arrow button to decrease the numeric value.
4. Use the **LEFT ◀** and **RIGHT ▶** arrow buttons to edit the next or previous numeric fields within the same row.
5. Once ready, press **ENTER/OK** to exit edit mode.

Menu Name	
Highlighted Item	Current Value
Menu Item	Highlighted Value
Menu Item	Value
	Value
	Value

List of values

Parameter	Value
	<input type="text"/>

Slider

Data		
Row	x: 0.658	y: 0.339
Highlighted Row	x: 0.315	y: 0.662
Row	x: 0.146	y: 0.043
Row	x: 0.276	y: 0.283

Numeric values

Notes



Some menu items may be unavailable due to settings in other menus. Unavailable menu items appear gray.

Using The Projector



Main menu

- **Input**
Press **ENTER/OK** to open the list of available inputs.
Use the **UP ▲** and **DOWN ▼** arrow buttons to select an input from the list, then press **ENTER/OK** to confirm your choice.
Press **EXIT** to return to the main menu.
- **Test Pattern**
Choose from:
...Off, White, Black, Red, Green, Blue, Checkerboard, Crosshatch, H Burst, V Burst, Colour Bars, Screen Layout.
Use the **LEFT ◀** and **RIGHT ▶** arrow buttons to switch between values.
- **Lens, Image, Color, Geometry, Edge Blend, Laser, Setup and Network**
Press **ENTER/OK** to open these menus and access various settings.

Press the **DOWN ▼** arrow at the bottom of the page to access additional menus:


- **PIP and Information**
Press **ENTER/OK** to open these menus and access various settings.


Press the **UP ▲** arrow to return to the previous page.



Main menu, page 1 and 2


Notes

 See [Signal Inputs](#) in the [Connection Guide](#) for further information about the available inputs and connections.

 Selecting a test pattern hides the OSD. Press **EXIT** to hide the test pattern, and then press **MENU** to show the OSD.

Lens menu

- **Lens Lock**
When this feature is **On**, all other **Lens** menu items are disabled.
- **Lens Control**
Opens a sub-menu, see below.
- **Center Lens**
Centers the lens.
- **Lens Type**
Choose a UST or a non-UST lens.
- **Lens Memory**
Opens a sub-menu, see next page.




Lens Control


Lens Control settings operate in **Zoom/Focus Adjustment** and **Shift Adjustment** mode. Press **ENTER/OK** to switch between modes.

When in **Zoom/Focus Adjustment** mode:

- Use the **UP ▲** and **DOWN ▼** arrow buttons to adjust **Zoom**.
- Use the **LEFT ◀** and **RIGHT ▶** arrow buttons to adjust **Focus**.



When in **Shift Adjustment** mode, use the arrow buttons to adjust **Shift**.



Notes


Lens menu continued from previous page

Lens Memory

This menu allows you to load, save and delete up to ten lens presets, containing position, zoom, focus and shift adjustment information.

For example, if using different screen sizes and aspect ratios, you can save zoom, focus and positioning for each screen size and aspect ratio in a dedicated preset.

Use **Clear Memory** to delete a memory preset if you need to save a new combination of lens settings in its place. Overwriting a saved memory preset is not possible.



Notes






Image menu

- **Dynamic Black**

Set to **On** to allow for increased contrast in darker scenes by modulating the light source.

- **Light Off Timer**

When **Dynamic Black** is **On**, the **Light Off Timer** will define if laser light source will turn off after a period of time has passed. The options are: **Disable, 0.5, 1.0, 1.5, 2.0, 3.0, 4.0** seconds.

- **Gamma**

Choose a de-gamma curve from **1.0, 1.8, 2.0, 2.2, 2.35, 2.5, S-Curve**, and **DICOM**. Used correctly, the **Gamma** setting can improve contrast while maintaining good details for blacks and whites.

If excess ambient light washes out the image and it is difficult to see details in dark areas, lower the **Gamma** setting to compensate. This improves contrast while maintaining good details for blacks. Conversely, if the image is washed out and unnatural, with excessive detail in black areas, increase the setting.

S-Curve is an enhanced mid-tone gamma.

DICOM is a simulated DICOM display, which can be used for training applications.

- **HDR**

Choose an HDR setting from **AUTO, HDRPQ-400, HDRPQ-500, HDRPQ-1000** and **HDRHLG**

Auto is the default setting. When a 4KUHD Blue-Ray player sends an HDR flag to the projector it will select the appropriate option according to the player data.

HDR (High Dynamic Range) is a new form of gamma developed to create more realistic experience when viewing images delivered using this format, such as scenes with bright sunlight. Unlike traditional gamma, HDR is not device or installation independent. HDR content will come with a recommended brightness regardless of screen size. For best results as a guideline the following screens sizes are suggested.

Image	
Dynamic Black	Off
Light Off Timer	Disable
Gamma	2.2
HDR	Auto
Brightness	100
Contrast	100
Saturation	100
Hue	100
Sharpness	10
Noise Reduction	Off
Freeze	
Resync	

Notes



Selecting an HDR setting will disable the Gamma setting.

If the HDR setting is Auto, the Gamma setting is only disabled when the image source is HDR.

HDR Screen sizes		Screen width (cm)		
Model	Lumens	400 NIT	500 NIT	1000 NIT
HLL4K	12,500	384cm	343cm	243cm

HDR options should only be used with media players and sources equipped with HDR and HDR content.

Perceptual Quantizer (PQ) is the digitizing concept for capture and display and provides metadata to enable the display to understand the coding of the content.

The NIT numbers relate to the brightness of the viewing conditions in NIT. NIT is the unit of brightness measurement for monitors and LED walls that emit light rather than reflect it such as a projection screen. However it is a reference to the brightness you would choose for a given environment.

HDRHLG is High Dynamic Range – hybrid-log-gamma. This is a broadcast version of HDR for live TV and events

Currently HDR gamma selection is manual.

- **Brightness, Contrast, Saturation, Hue, Sharpness**

Highlight the setting you wish to edit, and then press **ENTER/OK**, or the **LEFT** ◀ or **RIGHT** ▶ arrow button to open the slider.

Use the **LEFT** ◀ and **RIGHT** ▶ arrow buttons to adjust the slider.

Press **EXIT** to close the slider and return to the menu, or **MENU** to close the slider and return to the projected image.



- **Noise Reduction**

Choose a level of noise reduction from **Off, Low, Middle** and **High**.

- **Freeze**

Freezes the current frame.

- **Resync**

Press **ENTER/OK** to force the projector to resynchronise with the current input.



Notes

Color menu

Color Space

In most cases, the **Auto** setting determines the correct colorspace to use. If it does not, you can choose a specific colorspace:

Choose from **Auto**, **YPbPr**, **YCbCr**, **RGB PC** and **RGB Video**.



Notes



Color Space is not available with HDMI 3 or HDMI 4.

Color Mode

The projector can work in the following color modes: **ColorMax**, **Manual Color Matching**, **Color Temperature** and **Gains and Lifts**.

Color	
Color Space	Auto
Color Mode	ColorMax
ColorMax	ColorMax
Manual Color Match	Manual Color Matching
Color Temperature	Color Temperature
Gains and Lifts	Gains and Lifts


ColorMax

1. Set **Color Mode** to **ColorMax**.
2. Navigate to the **ColorMax** setting. Choose from **REC709**, **EBU**, **SMPTE**, **Peak**, **User 1** and **User 2**.

User 1 and **User 2** are user-defined color gamuts set via the **Setup > ColorMax** menu.

Color	
Color Space	Auto
Color Mode	ColorMax
ColorMax	Peak
Manual Color Matching	HDTV
Color Temperature	EBU
Gains and Lifts	User 1
	Peak
	User 1
	User 2

Notes

 Only one color mode can be selected at a time. Settings used by the other color modes are disabled.

 See [Setup menu](#) for further information about setting up the **User 1** and **User 2** color gamuts.




Color menu continued from previous page

Manual Color Matching


1. Set **Color Mode** to **Manual Color Matching**.
2. Open the **Manual Color Matching** submenu.

Here you can do the following:

- Switch **Auto Test Pattern On** and **Off**.
- Adjust **Hue**, **Saturation** and **Gain** settings for each individual color to improve the color balance of the projected image.
- Adjust white balance RGB values.
- Reset all values.



Notes


 For more details about the **Hue**, **Saturation** and **Gain** settings, see [Color matching parameters explained](#) further in this guide.

Color menu continued from previous page

Color matching parameters explained

The levels of hue, saturation and gain in the **Manual Color Matching** menu change the color values in the following ways:

- 1 Hue**
Specifies the position of each color (*red, yellow, green, cyan, blue* and *magenta*) relative to its neighboring colors.
- 2 Saturation**
Specifies the level of white in each color (i.e. how "pale" each color is).
- 3 Gain**
Controls the amount of light that goes into each color, i.e. the lowest gain would produce black.




Notes

Color menu continued from previous page

Color Temperature

1. Set **Color Mode** to **Color Temperature**.
2. Navigate to the **Color Temperature** setting. Choose a value from **3200K** (warmer) to **9300K** (cooler) or **Native** (no correction).



Notes

Color menu continued from previous page

Gains and Lifts

Lifts allow you to adjust black levels of individual colors, while gains adjust the bright part of the scale.

Set the sliders as required.

Gains and Lifts	
Red Lift	100 <input type="range"/>
Green Lift	100 <input type="range"/>
Blue Lift	100 <input type="range"/>
Red Gain	100 <input type="range"/>
Green Gain	100 <input type="range"/>
Blue Gain	100 <input type="range"/>
Reset	

Notes

Geometry menu

This menu allows you to compensate for image distortions caused by an unusual projection angle or irregular screen surface.

Geometry	
Aspect Ratio	Source
Digital Zoom	▶
Overscan	Off
Blanking	▶
Keystone	▶
4 Corners	▶
Rotation	▶
Pincushion / Barrel	▶
Arc	▶
Custom Warp	▶

Aspect Ratio


This feature defines the aspect ratio of the source. Use the **Setup > Screen Setting** to define the screen aspect ratio.


If you choose a preset aspect ratio from here, it will give you the best fit for your selection.

Choose from:


- **5:4**
- **4:3**
- **16:10**
- **16:9**
- **1.88**
- **2.35**
- **TheaterScope**
- **Source**
- **Unscaled**


Notes

 **Aspect Ratio, Digital Zoom and Overscan** are not available with input HDMI 3 or HDMI 4.

 Only one of the following should be used at any one time. **Keystone, 4 Corners, Rotation, Pincushion/Barrel and Arc**

For more complex adjustments use **Custom Warp** later in this section.


 Image scaling and aspect ratio are also influenced by **Setup > Screen Setting**.

 See next page for further information about the **TheaterScope** aspect ratio.


Theaterscope setting

The **TheaterScope** setting is used in combination with an anamorphic lens to restore 2.35:1 images packed into a 16:9 frame. Such images are projected with black lines at the top and bottom of the 16:9 screen to make up for the difference in aspect ratios.


Without an anamorphic lens and without the TheaterScope setting applied, a 16:9 source containing a 2.35:1 image looks like this:




If we change the setting to **TheaterScope**, the black lines will disappear but the image will stretch vertically to reach the top and bottom of the DMD™:




An anamorphic lens will stretch the image horizontally, restoring the original 2.35 ratio:



Notes

 TheaterScope is used with an anamorphic lens.

 If you use TheaterScope, set your screen aspect ratio to 16:9.


.Geometry menu continued from previous page

Digital Zoom

Digital zooming enlarges a section of the image, while the area outside the enlarged section is cropped out to preserve the overall image size.

- **Digital Zoom** defines the level of zoom that needs to be applied. If **Digital Zoom** is set to **0**, then the other settings in the menu will be disabled.
- **Digital Pan** and **Digital Scan** specify the area that is being enlarged:
 - **Digital Pan** adjusts the horizontal coordinates.
 - **Digital Scan** adjusts the vertical coordinates.

The **Reset** command restores the default **Digital Zoom**, **Digital Pan** and **Digital Scan** values.



Notes



Digital Zoom is a temporary setting and not retained after an input change or power cycle.


Geometry menu continued from previous page

Overscan

Use this setting to compensate for noisy or badly defined image edges.

Crop removes unwanted artifacts from the edges of your image by cropping the edges.

Zoom increases the size of the image to force the edges off-screen.



Notes





Image with noisy edges



Overscanned image

Geometry menu continued from previous page


Blanking

Use this feature to:

- fit an odd-sized screen;
- cut off timecode dots in the top line of a picture;
- cut off subtitles, etc.

Select the edge you wish to blank and use the **LEFT** ◀ and **RIGHT** ▶ arrow buttons to determine the amount of correction.

Use the **Reset** command to restore blanked edges.




Notes

Geometry menu continued from previous page

Keystone


Use this setting to compensate for any distortion caused by the projector being in a different horizontal or vertical plane to the screen.



Notes

Keystone example


- 1 The projector is positioned at an angle
- 2 The resulting image is distorted
- 3 The image is corrected when Keystone is applied



Geometry menu continued from previous page

Keystone settings

- 1 Projector to the left**
 The projector is positioned to the left of the screen.
 To correct, apply a positive **Horizontal Keystone** value using the **RIGHT** arrow button.
- 2 Projector to the right**
 The projector is positioned to the right of the screen.
 To correct, apply a negative **Horizontal Keystone** value using the **LEFT** arrow button.
- 3 Projector high**
 The projector is positioned above the screen at a downward angle.
 To correct, apply a negative **Vertical Keystone** value using the **DOWN** arrow button.
- 4 Projector low**
 The projector is positioned below the screen at an upward angle.
 To correct, apply a positive **Vertical Keystone** value using the **UP** arrow button.
- 5 Projector straight**
 The projector is directly opposite the screen at a right angle both horizontally and vertically.
 No correction is needed.



Horizontal and vertical keystone corrections

Notes

Geometry menu continued from previous page


4 Corners

For each corner, apply horizontal and / or vertical correction as necessary to restore the rectangular shape of the image.




Top Right Corner example


In this illustration, the top right corner requires both horizontal and vertical correction.



Top Right Corner correction



Notes

 Corner corrections provide a simple setup for awkward installations and irregular shaped screens that may distort the image. To apply a similar (but less flexible) correction, while preserving the original aspect ratio of the image, use the **Keystone** menu.



Geometry menu continued from previous page

Rotation

Use this feature for example to correct a mounting error causing the image not to be level with the screen.

Rotation example

- 1 DMD™ area**
The DMD™ is not rotated. It still covers the area that would be occupied by the image without correction.
- 2 Rotated image**
The image is smaller than the surrounding DMD™ area. It is scaled in order to remain within the DMD™ area.
- 3 Angle of rotation**
The angle equals a quarter of the **Rotation** setting.
In this example the angle is 5°, therefore **Rotation = 20**.



Notes


Geometry menu continued from previous page

Pincushion / Barrel

Pincushion or barrel distortions are the result of poor or incorrect tensioning of the screen or using a surface that is not flat.

Use the **Pincushion / Barrel** control to compensate electronically for such distortions.

You can also use this menu to make simple panoramic screen corrections without using external processors.



Notes

Pincushion / Barrel example

The illustration shows pincushion and barrel correction applied both horizontally and vertically, in equal measures.



Pincushion



Barrel

Geometry menu continued from previous page

Arc

This feature is similar to **Pincushion / Barrel** but allows you to apply curvature to each edge of the image independently so you can have any combination of corrections.



Arc

Top	0	<input type="range"/>
Bottom	0	<input type="range"/>
Left	0	<input type="range"/>
Right	0	<input type="range"/>
Reset		

Notes



Please note that a positive **Arc** value on any edge will reduce the image size as the projector needs to maintain the aspect ratio.



A negative **Arc** value will not affect the overall image size.

Geometry menu continued from previous page

Custom Warp

This feature permits selection of predefined User warp maps. User custom warp maps require the Projector Controller PC application to create the custom warp.

Custom warp maps provide non-linear curvature correction for curved or spherical screens and other irregular shaped surfaces such as building mapping




Notes

Edge Blend menu

Use this menu to blend together images from an array of two or more projectors.


The feature feathers the light output of the projector within the edges that overlap with other projectors in the array: as a result, the overlapping edges are evenly lit and easily blend in with the rest of the image.

- **Edge Blend**
Enable and disable **Edge Blend**
- **Align Pattern**
Add markers to the image showing the edges of the blend area and making the overlaps more visible to help adjust the physical position of the projectors in the array.
- **Blend Width**
Determine the width of the blended regions.
- **Black Level Uplift**
Adjust black levels to compensate if the blended regions appear brighter than the rest of the image.
- **Reset**
Reset all **Edge Blend** settings to their factory default values.



Notes


 When **Edge Blend** is set to **Off**, all other edge blend settings are disabled.

 The picture in the blend region needs to be delivered to all overlapping projectors, which may require a special setup of the source.

Edge Blend menu continued from previous page

Blend Width

Use the **LEFT** ◀ and **RIGHT** ▶ arrow buttons to set the width of the blended regions:



Blend Width	
Top	0 ██████████
Bottom	0 ██████████
Left	0 ██████████
Right	0 ██████████

Notes

Edge Blend menu continued from previous page

Black Level Uplift


Black in the blended regions appears less dark than in the rest of the image. To compensate for this, use this menu to raise the black levels of the rest of the image:

- Set **All** to the required amount of black level correction. This will apply equal correction to the black levels of all colors.
- If necessary, use the individual color sliders (**Red**, **Green** and **Blue**) for fine adjustment.

You may experience artifacts at the edges where the blended region of one projector overlaps the **pond of mirrors** of its neighbor. In the example below, the blended image comes from **two projectors**, **1** and **2**. Both images have black level uplift applied; as a result, **artifacts 3** and **4** have emerged at the edges where the black level uplift region of one projector overlaps the pond of mirrors of the other.

To remove the artifacts, you need to slightly reduce the size of the black level uplift region of each projector so it does not overlap the pond of mirrors of the other projector.

- Depending on your array, use **Top**, **Bottom**, **Left** and/or **Right** to reduce the black level uplift size. In the example below, use the **Right** slider of the **projector on the left 1** to remove the **artifact on the right 4**, and the **Left** slider of the **projector on the right 2** to remove the **artifact on the left 3**.



Black Level Uplift

Select Area	
Top	0
Bottom	0
Left	0
Right	0
Colour Adjustment	
All	◀ ▶
Red	0
Green	0
Blue	0

Notes

Enable **Align Pattern** from the **Edge Blend** menu to see the black level uplift area.


Laser menu

- **Power Mode**

- **Eco** will automatically set the laser power to 80%.
- **Normal** will set the power to 100%.
- Set to **Custom** if you wish to adjust the power manually.

- **Power Level**

This setting is only available if **Power Mode** is set to **Custom**.
Choose a value between 20 and 100, ranging from 20% to 100% laser power.



Notes

Setup menu

- Orientation**
 Choose from **Front Tabletop**, **Front Ceiling**, **Rear Tabletop**, **Rear Ceiling** and **Auto-front**.
- High Altitude**
 Choose from **On**, **Auto** and **Quiet**.
- Standby Power**
 Choose from **SuperECO**, **ECO** and **Normal**.
SuperECO uses minimal power and disables power ON via LAN.
ECO uses a low power setting but enables power ON via Ethernet port only.
Normal enables power ON via both HDBase-T/LAN and Ethernet ports.
- Screen Setting**
 Choose from **16:10**, **16:9** and **4:3**.
- ColorMax**
 Set up user-defined color gamut values.
- Power On/Off Management**
 Access the submenu to set up automatic projector power on and power off.
- Clock Adjust**
 Access the submenu to set current date and local time.
- Startup Logo**
 Set this to **On** if you want the DP logo to show when the projector is first switched on.
- Blank Screen**
 Choose from **Logo**, **Black**, **Blue** and **White**.
- Auto Source**
 If this setting is **On**, the projector will automatically search for an active input source.

Highlight the **DOWN ▼** arrow at the bottom of the page and press **ENTER/OK** to navigate to the second **Setup** menu page.

Setup	
Orientation	Auto-front
High Altitude	Auto
Standby Power	SuperECO
Screen Setting	16:9
ColorMax	▶
Power On/Off Management	▶
Clock Adjust	▶
Startup Logo	On
Blank Screen	Logo
Auto Source	Off
▼	

Notes



Auto-front automatically detects the projector's position and sets Table or Ceiling orientation accordingly.

Setup menu continued from previous page

- **Trigger1 and Trigger 2**
Choose from **Screen, 5:4, 4:3, 16:10, 16:9, 1.88, 2.35, TheaterScope, Source, Unscaled** or **RS232** to determine what will cause each trigger output to activate.
- **Infrared Remote**
Set to **Off** if you wish to disable the remote control.
- **IR Code**
The projector and the remote control need a matching IR code: a two-digit number between **00** and **99**.

The default IR code is **00**. This is also a master code, which, if assigned to a remote, will work regardless of the value assigned to the projector.
To assign an IR code for the projector:
 1. Select **IR Code**.
 2. Use the **UP ▲** and **DOWN ▼** arrow buttons to change the values.**To assign an IR code for the remote:**
 1. Press and hold the **ADDR** button on the remote until the indicator starts flashing.
 2. Release the **ADDR** button and while the indicator is still flashing, enter a two-digit address using the numeric input buttons. The indicator will flash three times quickly to confirm the change.
- **IR Code Reset**
Use this command to unassign an IR code from the projector. This will revert the **IR Code** value to **00**.

To unassign an IR code from the remote control,
 - Press and hold **ALT** and **ADDR** simultaneously until the indicator flashes to confirm the change.
- **OSD Settings**
Access this submenu to adjust the appearance and position of the on-screen display.
- **Memory**
Access this submenu to save up to four presets containing custom combinations of image settings, or to recall a saved preset.
- **Instant Startup**
When **ON** only the Laser will be turned off when the Power off command is given. A subsequent Power On will turn on the laser giving an apparent very fast power on.

Setup	
Trigger-1	Off ▲
Trigger-2	Off
Infrared Remote	On
IR Code	0
IR Code Reset	
OSD Settings	▶
Memory	▶
Instant Startup	Off
Standby Period	30 Min.

Notes

If you turn the remote control off, you can only turn it back on again from the control panel or via the **Projector Controller** application.

The **Projector Controller** software is available for download from the Digital Projection website, free of charge.



A wired remote control will also be disabled if **Infrared Remote** is set to **Off**.

Setup menu continued from previous page

- **Standby Period**

Used with Instant Startup. If Instant Startup in **ON** and the projector is powered down then the projector will go to Standby after the selected "Standby Period" 30 minutes, 60 minutes, 90 minutes.

Highlight the **UP ▲** arrow at the top of the page and press **ENTER/OK** to go back to the first **Setup** menu page.

Notes

Setup menu continued from previous page

ColorMax

ColorMax permits seven point color matching of red, green, blue, yellow, cyan, magenta and white.

You can enter your own gamut values here, or edit values you have imported using the **Projector Controller** software.

Defining your own colorspace with individual x and y coordinates for each color enables you to match not only the whites but each individual color as well.

Highlight the submenu you wish to open and press **ENTER/OK** to confirm your choice.





Measured Data / Target Data

1. Use the **UP ▲** and **DOWN ▼** arrow buttons to highlight a color, then use the **LEFT ◀** and **RIGHT ▶** arrow buttons to navigate to the **x** or **y** coordinate.
2. Use the **UP ▲** and **DOWN ▼** arrow buttons to increase and decrease the value, respectively.
3. Exit edit mode:
 - press **ENTER/OK**, if you want to save the edited values.
 - press **EXIT**, if you do not wish to save the edited values
4. If necessary, highlight another color and repeat the procedure.

Measured Data		
Red	x: 0.658	y: 0.339
Green	x: 0.315	y: 0.662
Blue	x: 0.146	y: 0.043
White	x: 0.276	y: 0.283
Reset		

Target Data – User 1		
Red	x: 0.640	y: 0.390
Green	x: 0.300	y: 0.600
Blue	x: 0.150	y: 0.060
Yellow	x: 0.419	y: 0.505
Cyan	x: 0.225	y: 0.329
Magenta	x: 0.321	y: 0.154
White	x: 0.285	y: 0.302

Notes

-  *The **Projector Controller** software is available for download from the Digital Projection website, free of charge.*
-  *This tool is best used in conjunction with a specialized light meter (a photo spectrometer) to measure color parameters within a particular installation. However, the preloaded generic factory default data set is designed to give more than satisfactory results.*

Setup menu continued from previous page

Power On/Off

- **Auto Power Off**

Set this to On if you want the projector to go into STANDBY mode when no input source is detected for 20 minutes.

- **Auto Power On**

Set this to **On** if you want the projector to start up immediately when the mains is connected.

Set this to **Off** if you want the projector to go into STANDBY mode when the mains is connected. In this case, the projector will not start up until the **POWER** button is pressed on the control panel or the **ON** button is pressed on the remote control.



- **Scheduled on/off**

Access this submenu to create a weekly schedule for automatic on and off times:

1. Set a schedule:

- Use the **UP ▲** and **DOWN ▼** arrow buttons to highlight a row, then press **ENTER/OK** to enable edit mode.
- Within a row, navigate with the **LEFT ◀** and **RIGHT ▶** arrow buttons. Set values with the **UP ▲** and **DOWN ▼** arrow buttons.
- To exit edit mode, press **ENTER/OK**. Alternatively, press **EXIT** if you don't want the changes to take effect. Move to another row using the **UP ▲** and **DOWN ▼** arrow buttons.

2. To enable the schedule, set **Schedule** to **On**.



Notes

Setup menu continued from previous page

Clock Adjust

Use this menu to set date (in **dd:MM:yyyy** format), time (in **HH:mm** format) and time zone.

The date and time set here will affect any schedule created within the **Power On/Off** menu.



Notes

Setup menu continued from previous page

OSD Settings

- **Language** sets the OSD language.
- **Menu Position** determines where the OSD should appear on the screen when activated.
- **Menu Transparency** sets OSD transparency between **0%** (no transparency), **25%**, **50%** and **75%**.
- **Time Out** determines how long the OSD should remain on screen if no buttons are pressed. Choose **Always On** to disable this feature.
- **Message Box** determines whether projector status messages should appear on the screen.

Memory

The current image settings can be saved as a preset, which you can recall later. The default settings can be recalled at any time as well.

Up to four custom presets can be stored for each input.

The following settings are saved in a preset:

- From the **Image** menu — **Dynamic Black, Gamma, HDR, Brightness, Contrast, Saturation, Hue, Sharpness** and **Noise Reduction**
- From the **Color** menu — **Color Space, Color Mode, ColorMax, Color Temperature, Dynamic Black, RGB Lift** and **RGB Gain**
- From the **Geometry** menu — **Aspect Ratio** and **Overscan**

To recall a saved preset:

- Select **Recall Memory** and press **ENTER/OK**, then select a preset from **Preset A** to **Preset D**. Select **Default** to load factory default values.

To save a preset:

- Select **Save Settings** and press **ENTER/OK**, then choose from **Preset A, Preset B, Preset C** and **Preset D**.

OSD Settings	
Language	English
Menu Position	Center
Menu Transparency	0
Time Out	30 Seconds
Message Box	On

Memory	
Recall Memory	Default
Save Settings	Preset A

Notes



Presets from one input cannot be applied to another input.

Network menu

- **DHCP, IP, Subnet Mask, Gateway, DNS**

Set **DHCP** to **On** if the IP address is to be assigned by a DHCP server, or **Off** if it is to be set here.

If **DHCP** is **On**, it will not be possible to edit **IP Address, Subnet Mask, Gateway** or **DNS**.

If **DHCP** is set to **Off**, edit **IP Address, Subnet Mask, Gateway** and **DNS** as required.

- **MAC**

This field is read-only.

- **AMX**

Switch on or off.

Network	
DHCP	Off
IP	192 . 168 . 000 . 100
Subnet Mask	255 . 255 . 255 . 000
Gateway	000 . 000 . 000 . 000
DNS	000 . 000 . 000 . 000
MAC	00: 18: 27: 2d: f2: 06
AMX	Off

Notes

PIP menu

- **PIP**
Turn PIP on and off.
- **Source**
Select an input source for the PIP image.
Any combinations are possible between main and PIP input source, as long as one of the inputs is either **DisplayPort** or **3G-SDI**.
- **Position**
Set the location of the PIP image on the screen. Choose from **Top-Left**, **Top-Right**, **Bottom-Left**, **Bottom-Right** and **PBP**.

PIP	
PIP	Off
Source	HDMI1
Position	Top-Left

Notes

Information menu

This menu gives information about software and hardware configuration, input source and laser operating times. It also allows you to restore the factory default settings.

Information	
Model Name	HIGHlite Laser 4K 12000
Serial Number	X000XXXXX0000
Software Version 1	MD17-VD21-1.14-20170828
Software Version 2	STEP3_E01-23-17-3120
Software Version 3	2.0.14.0
Active / PIP Source	HDMI 1
Signal Format	▶
Laser Hours	2
System Status	▶
Thermal Status	▶
Factory Reset	

Notes

Signal Format

Signal Format	
Active Source	
Timing	1080p/60Hz
H Refresh	67.500 KHz
V Refresh	60.00 Hz
Pixel Clock	148.500 MHz
PIP Source	
Timing	576p/50Hz
H Refresh	31.250 KHz
V Refresh	50.00 Hz
Pixel Clock	27.0 MHz

Information menu continued from previous page

System Status

System Status	
Atmospheric Pressure	98988 Pa (116 m)
AC Voltage	160V – 264V
Ceiling Mode	0
Tilt Angle	4 deg
Portrait Angle	0 deg
Altitude Mode	Low
Laser Power	100%
License Key	License Pass. Timeout Not Expired

Notes

Thermal Status


Thermal Status	
Inlet/DMD Temp.	23 / 24 (C)
PW Temp.	58 (C)
LD 1-6 Temp.	41 / 46 / 41 / 48 / 49 / 49 (C)
Fan 1-3 Speed	1399 / 1402 / 1391
Fan 4-6 Speed	1410 / 1200 / 1205
Fan 7-9 Speed	1211 / 1407 / 1410
Fan 10-12 Speed	0 / 3005 / 3007
Fan 13-15 Speed	2986 / 2984 / 2984
Fan 16-18 Speed	3020 / NA / NA
Fan 19-21 Speed	1200 / 1204 / 1200
Fan 12-24 Speed	2283 / 2332 / 1800
Water Pump Speed	2718 / 3378 / 3220

Information menu continued from previous page

Factory Reset

To restore the factory default settings:

1. Navigate to **Factory Reset** and press **ENTER/OK**.
2. When prompted, press **ENTER/OK** to confirm your choice, or press **EXIT** to cancel.



Notes

Factory reset does not reset the Network settings, or High Altitude mode.

Served Web Pages

The served web pages allow you to control the projector remotely via LAN.

The default IP address is **192.168.0.100**.

The screenshot displays the Digital Projection web interface. At the top left is the logo with the text "DIGITAL PROJECTION". Below the logo is a navigation menu with the following items: Projector Status, Projector Control, Crestron RoomView, Network Setup, Alert Mail Setup, Date/Time Setup, Error Log, and DP OSD Function. Under "DP OSD Function", there are three buttons: Hot Key, PicMute OSD, and Freeze. The main content area is divided into two sections: "Projector Information" and "LAN Information".

Projector Information

Model	HIGHlite Laser 4K 12000	
Serial Number	W713ZDUCY0018	
Software Version 1	MP03-VP05-1.1.4-20171220	
Software Version 2	STP3_E01-23-17-3120	
Software Version 3	2.0.23.0	
Power Status	Power On	
Input	HDMI 1	
Laser Status	Power : On	Runtime : 71 H
Projection Mode	Front Tabletop	
High Altitude	Auto	
Inlet Temperature	21	°C
DMD Temperature	33	°C
LD Temperature	42 / 36 / 37 / 41 / 43 / 42	°C
Diagnostic Status	No Error	

LAN Information

MAC address	00:18:23:50:4E:06
-------------	-------------------

Notes

DIGITAL PROJECTION

Projector Status

Projector Control

Crestron RoomView

Network Setup

Alert Mail Setup

Date/Time Setup

Error Log

DP OSD Function

Hot Key
PicMute OSD
Freeze

State Control

Power
On Off

Input Selection
DisplayPort HDMI 1 HDMI 2
HDBaseT 3G-SDI

Lens Control

Zoom In Focus In Shift

Zoom OUT Focus OUT

The interface features a light blue background with a central control area. The 'State Control' section contains 'Power' (On/Off) and 'Input Selection' (DisplayPort, HDMI 1, HDMI 2, HDBaseT, 3G-SDI) buttons. The 'Lens Control' section contains a grid of arrow buttons for Zoom In, Focus In, Shift, Zoom OUT, and Focus OUT.


Notes

The screenshot displays the 'DIGITAL PROJECTION' web interface. On the left is a navigation menu with the following items: Projector Status, Projector Control, Crestron RoomView, Network Setup (highlighted), Alert Mail Setup, Date/Time Setup, Error Log, and DP OSD Function. Below the menu are 'Hot Key' controls: PicMute, OSD, and Freeze. The main content area is titled 'NetWork' and contains the following settings:

- DHCP:** On Off
- IP Address:** 192 . 168 . 0 . 100
- Subnet Mask:** 255 . 255 . 255 . 0
- Gateway:** 192 . 168 . 0 . 254
- DNS Server:** 192 . 168 . 0 . 1

A 'Save Settings' button is located below the IP address fields. At the bottom of the settings area, it says: **AMX:** Off ON. A **CAUTION:** message reads: 'Incorrect settings may cause the projector to lose network connectivity. Please close webpage and reload when you settings.'

Notes



Notes

DIGITAL PROJECTION

- Projector Status
- Projector Control
- Crestron RoomView
- Network Setup
- Alert Mail Setup
- Date/Time Setup
- Error Log
- DP OSD Function

Hot Key
PicMute OSD
Freeze

Server Setup

SMTP Server: Port:
User Name:
Password:

Mail

E-mail Alert: Enable Disable
From:
To:
CC:
Projector Name:
Location:

Test

Periodic Report

days Sun Mon Tue Wed Thu Fri Sat

Times

<input type="checkbox"/> 00:00	<input type="checkbox"/> 01:00	<input type="checkbox"/> 02:00	<input type="checkbox"/> 03:00
<input type="checkbox"/> 04:00	<input type="checkbox"/> 05:00	<input type="checkbox"/> 06:00	<input type="checkbox"/> 07:00
<input type="checkbox"/> 08:00	<input type="checkbox"/> 09:00	<input type="checkbox"/> 10:00	<input type="checkbox"/> 11:00
<input type="checkbox"/> 12:00	<input type="checkbox"/> 13:00	<input type="checkbox"/> 14:00	<input type="checkbox"/> 15:00
<input type="checkbox"/> 16:00	<input type="checkbox"/> 17:00	<input type="checkbox"/> 18:00	<input type="checkbox"/> 19:00
<input type="checkbox"/> 20:00	<input type="checkbox"/> 21:00	<input type="checkbox"/> 22:00	<input type="checkbox"/> 23:00

Notes

DIGITAL PROJECTION

Projector Status
Projector Control
Crestron RoomView
Network Setup
Alert Mail Setup
Date/Time Setup
Error Log
DP OSD Function

Hot Key
PicMute OSD
Freeze

Time Zone:

Time Zone: UTC(-11:00) ▼
Select Local time zone, Current zone is UTC +00:00
SaveTimeZone

Time:

Date: 2018.01.30 e.g.2000.01.01
Clock: 12:04 e.g.23:59
Current time is set to :2018.01.30 ; 12:04
SaveTime

DIGITAL PROJECTION

Projector Status
Projector Control
Crestron RoomView
Network Setup
Alert Mail Setup
Date/Time Setup
Error Log
DP OSD Function

Hot Key
PicMute OSD
Freeze

Projector Error Log

ErrLog: 4 / Current PowerOn times: 8

No	Code	PwrOn	L1(Hr/Pwr)	T(Ti/Tc)	Desc
1	1161	7	31/2	13/13	ErrFrontCoverOpen
2	1141	6	31/2	18/20	ErrLensSwitchOpen
3	1151	3	5/2	21/26	ErrCoverDoorOpen
4	1151	2	5/2	22/28	ErrCoverDoorOpen

Page 1 Page 2

Notes

Notes

Page 1 Page 2 Page 3

Projector Status

Projector Control

Crestron RoomView

Network Setup

Alert Mail Setup

Date/Time Setup

Error Log

DP OSD Function

Hot Key
PicMute OSD
Freeze

Input

- Input: HDMI1

Test Pattern

Exit Test Pattern

Lens

- Lens Lock: off on
- CenterLens: Do
- LensMemory: Memory 1 Save Load Clear

Image

- DynamicBlack: off on
- Light Off Timer: Disable
- Gamma: 2.2
- HDR Mode: HDR Auto
- Brightness: + 112
- Contrast: + 87
- Staturation: + 130
- Hue: + 100
- Sharpness: + 0
- Noise Reduction: off
- Freeze
- Resync

color

- ColorSpace: Auto
- ColorMode: ColorMax
- ColorMax: Peak
- Manual Color Matching
- Red**
 - Hue: + 250
 - Saturation: + 250
 - Gain: + 250
- Green**
 - Hue: + 250
 - Saturation: + 250

Gain: + 250

Green

- Hue: + 250
- Saturation: + 250
- Gain: + 250

Blue

- Hue: + 250
- Saturation: + 250
- Gain: + 250

Yellow

- Hue: + 220
- Saturation: + 250
- Gain: + 250

Magenta

- Hue: + 280
- Saturation: + 250
- Gain: + 250

Cyan

- Hue: + 230
- Saturation: + 250
- Gain: + 250

White Balance

- Red: + 250
- Green: + 250
- Blue: + 250

Manual Color Matching Reset

- Color Temperature: Native
- Gains and Lifts
- Red Lift: + 100
- Green Lift: + 100
- Blue Lift: + 100
- Red Gain: + 100
- Green Gain: + 100
- Blue Gain: + 100

Gains and Lifts Reset

DIGITAL PROJECTION

Page 1 Page 2 Page 3

Projector Status

Projector Control

Crestron RoomView

Network Setup

Alert Mail Setup

Date/Time Setup

Error Log

DP OSD Function

Hot Key
PicMute OSD
Freeze

geometry

- Aspect Ratio Source
- Digital Zoom
 - Digital Zoom - + 0%
 - Digital Pan - + 0
 - Digital Scan - + 0
 - Digital Zoom Reset
- Overscan Off
- Blanking
 - Top - + 0
 - Bottom - + 0
 - Left - + 0
 - Right - + 0
 - Blanking Reset
- Keystone
 - H Keystone - + 0
 - V Keystone - + 0
 - Rotation - + 0
 - Keystone Reset
- 4 Corners
 - Top Left Corner X - + 0
 - Top Left Corner Y - + 0
 - Top Right Corner X - + 0
 - Top Right Corner Y - + 0
 - Bottom Left Corner X - + 0
 - Bottom Left Corner Y - + 0
 - Bottom Right Corner X - + 0
 - Bottom Right Corner Y - + 0
 - 4 Corners Reset
- Rotation
 - Rotation - + 0
 - Rotation Reset
- Pincushion/Barrel
 - H Pin/Barrel - + 0
 - V Pin/Barrel - + 0
 - Keystone
 - H Keystone - + 0
 - V Keystone - + 0
 - Rotation - + 0
 - Pincushion/Barrel Reset
- Arc
 - Top - + 0
 - Bottom - + 0
 - Left - + 0
 - Right - + 0
 - Arc Reset
- Custom Warp Off

edgeblend

- Edge Blend off on
- Align Pattern off on
- Blend Width
 - Top - + 0
 - Bottom - + 0
 - Left - + 0
 - Right - + 0
- Black Level Uplift
 - Select Area
 - Top - + 0
 - Bottom - + 0
 - Left - + 0
 - Right - + 0
- Color Adjustment
 - All - +
 - Red - + 0
 - Green - + 0
 - Blue - + 0

Edgeblend Reset

laser

- Power Mode Custom
- Power Level - + 70

Notes

OSD Setting

- Language: English
- Menu Position: Center
- Menu Transparency: 0
- Time Out: 30 Seconds
- Message Box: off on
- Memory:
 - Recall Memory: Preset B
 - Save Settings: Preset A
- Instant Startup: off on
- Standby Period: 30 Min.

pip

- PIP: off on
- Source: DisplayPort
- Position: Top-Left

information

- Model Name: HIGHlite Laser 4K 12000
- Serial Number: W713ZDUCY0018
- Software Version 1: MP03-VP05-1.1.4-20171220
- Software Version 2: STP3_E01-23-17-3120
- Software Version 3: 2.0.23.0
- Active/PIP Source: HDMI1/NA
- Signal Format:
 - Active Source: HDMI1
 - Timing: 3840x2160
 - H Refresh: 134.8 kHz
 - V Refresh: 59.9 Hz
 - Pixel Clock: 593.24 MHz
- Laser Hours: 71
- System Status:
 - Atmospheric Pressure: 101284 Pa(3 m)
 - AC Voltage: 180V-264V
 - Altitude Mode: Auto
 - Laser Power: 70
 - License Key: License Pass, Timeout Not Expired
- Thermal Status:
 - Inlet Ti1/DMD Temp.: 21 /32
 - PW Temp.: 46
 - LD B1~B6 Temp.: 39 / 34 / 34 / 39 / 40 / 40
 - Fan 1-3Speed: 1204/1206/1034
 - Fan 4-6Speed: 961/960/1004
 - Fan 7-9Speed: 1242/1007/1149
 - Fan 10-12Speed: 1008/4551/2776
 - Fan 13-15Speed: 2808/2234/1300
 - Fan 16-18Speed: 1797/1800/1008
 - Fan 19-21Speed: 990/1007/1009
 - Fan 22-24Speed: 2304/2302/1800
 - Water Pump Speed: 2522/3226/3050

Factory Reset

This page is intentionally left blank.



HIGHlite Laser 4K Series

High Brightness Digital Video Projector

▶ REFERENCE GUIDE



IN THIS GUIDE

Choosing A Lens..... 83

Basic calculation.....84

Basic calculation example85

Full lens calculation.....86

 Introducing TRC.....86

 Calculating TRC.....87

 Calculating the throw ratio with TRC.....88

Full lens calculation example89

Screen Requirements 90

Fitting the image to the display90

 4K-UHD images displayed full width.....90

 4K-UHD images displayed with a height of 2160 pixels91

 4K-UHD images displayed full height92

Diagonal screen sizes.....93

Positioning The Image 94

Aspect Ratios Explained 96

Aspect ratio examples97

Appendix A: Lens Part Numbers..... 99

Appendix B: Supported Signal Input Modes 100

 2D formats 100

 SDI Format..... 102

Appendix C: Wiring Details 104

Signal inputs and outputs 104

 HDMI 1 and 2..... 104

 DisplayPort..... 105

 3G-SDI In, 3G-SDI Out 106

Control connections 107

LAN 107

RS232 107

Trigger 1 & Trigger 2 108

IR input..... 108

Appendix D: Glossary Of Terms..... 109

Choosing A Lens

A number of lenses are available. Which lens you choose depends on the screen size, image aspect ratio, throw distance and light output.

The following table shows all available lenses in order of their **throw ratios**:

Throw ratios	Throw distance range
0.77 : 1 fixed lens	1.3 - 15 m (4.3 - 49.2 ft)
0.96 - 1.43 : 1 zoom lens	1.8 - 10.0 m (5.9 - 32.8 ft)
1.16 : 1 fixed lens	1.4 - 25 m (4.6 - 82 ft)
1.45 - 1.74 : 1 zoom lens	1.8 - 9.3 m (5.9 - 30.5 ft)
1.74 - 2.17 : 1 zoom lens	2.2 - 11.8 m (7.2 - 38.7 ft)
2.17 - 2.90 : 1 zoom lens	2.7 - 15.4 m (8.9 - 50.5 ft)
2.90 - 4.34 : 1 zoom lens	3.6 - 22.5 m (11.8 - 73.8 ft)
4.34 - 6.76 : 1 zoom lens	5.5 - 35 m (18 - 114.8 ft)

To choose a lens, either calculate the **throw ratio** required, or use the **lens charts** provided in Appendix B at the end of this document.

Notes



For information about individual lens part numbers, see [Appendix A](#) at the end of this document.



See also [Appendix B: Lens Charts](#) at the end of this document.



Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.



For further information about using the right lens and hood, see [The lens hood](#) in the **Installation and Quick-Start Guide**.

Basic calculation

Identify the required lens by calculating the **throw ratio**.


A **throw ratio** is the ratio of the throw distance to the screen width:

$$\text{Throw ratio} = \frac{\text{Throw distance}}{\text{Screen width}}$$

1. Use the formula above to obtain the required throw ratio.
2. Match the throw ratio with a lens from the table below:

Throw ratios	Throw distance range
0.77 : 1 fixed lens	1.3 - 15 m (4.3 - 49.2 ft)
0.96 - 1.43 : 1 zoom lens	1.8 - 10.0 m (5.9 - 32.8 ft)
1.16 : 1 fixed lens	1.4 - 25 m (4.6 - 82 ft)
1.45 - 1.74 : 1 zoom lens	1.8 - 9.3 m (5.9 - 30.5 ft)
1.74 - 2.17 : 1 zoom lens	2.2 - 11.8 m (7.2 - 38.7 ft)
2.17 - 2.90 : 1 zoom lens	2.7 - 15.4 m (8.9 - 50.5 ft)
2.90 - 4.34 : 1 zoom lens	3.6 - 22.5 m (11.8 - 73.8 ft)
4.34 - 6.76 : 1 zoom lens	5.5 - 35 m (18 - 114.8 ft)

3. Ensure the required throw distance is within the range covered by the lens.



- 1 Screen width
- 2 Throw distance

Notes

The basic calculation on this page does not take into consideration DMD™ and image size, which could affect the throw ratio. For a more complex and realistic calculation, see [Full lens calculation](#) in this section.

When calculating the throw ratio, be sure to use identical measurement units for both the throw distance and the screen width.

For information about individual lens part numbers, see [Appendix A](#) at the end of this document.

See also [Appendix B: Lens Charts](#) at the end of this document.

Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.

For further information about using the right lens and hood, see [The lens hood](#) in the *Installation and Quick-Start Guide*.

Basic calculation example

1. Calculate the throw ratio using the formula.

Your screen is **4.5 m** wide and you wish to place the projector approximately **11 m** from the screen. The throw ratio will then be

$$\frac{11}{4.5} = 2.44$$

2. Match the result with the lens table.

The lens matching a throw ratio of 2.44 is **the 2.17 - 2.90 : 1 zoom lens**.

3. Check whether the lens covers the required throw distance.

The range quoted for the 2.17 - 2.90 : 1 zoom lens is **2.7 - 15.4 m**. The required distance of 11 m is within the range.

INFORMATION YOU NEED FOR THIS CALCULATION

- The throw ratio formula:

$$\text{Throw ratio} = \frac{\text{Throw distance}}{\text{Screen width}}$$

- The lens table:

Throw ratios	Throw distance range
0.77 : 1 fixed lens	1.3 - 15 m (4.3 - 49.2 ft)
0.96 - 1.43 : 1 zoom lens	1.8 - 10.0 m (5.9 - 32.8 ft)
1.16 : 1 fixed lens	1.4 - 25 m (4.6 - 82 ft)
1.45 - 1.74 : 1 zoom lens	1.8 - 9.3 m (5.9 - 30.5 ft)
1.74 - 2.17 : 1 zoom lens	2.2 - 11.8 m (7.2 - 38.7 ft)
2.17 - 2.90 : 1 zoom lens	2.7 - 15.4 m (8.9 - 50.5 ft)
2.90 - 4.34 : 1 zoom lens	3.6 - 22.5 m (11.8 - 73.8 ft)
4.34 - 6.76 : 1 zoom lens	5.5 - 35 m (18 - 114.8 ft)

Notes



The basic calculation on this page does not take into consideration DMD™ and image size, which could affect the throw ratio. For a more complex and realistic calculation, see [Full lens calculation](#) in this section.



For information about individual lens part numbers, see [Appendix A](#) at the end of this document.

Full lens calculation

Introducing TRC

The choice of lens will affect the image size and will address discrepancies between the DMD™ resolution and the source.

When an image fills the height of the DMD™ but not the width, it uses less than 100% of the DMD™ surface. A lens chosen using the basic formula may produce an image that is considerably smaller than the actual screen.

To compensate for loss of screen space in such situations, you need to increase the throw ratio using a **Throw Ratio Correction (TRC)**.

Example

Fig. 1 illustrates a 4:3 image within a 4K-UHD Display.

When a 4K-UHD projector is used for a 4:3 image, the image does not fill the width of the DMD™, creating a **pillarboxing** effect - blank spaces to the left and right.

Fig. 2 shows the same image projected on a 4:3 screen using a standard lens (chosen with the basic calculation).

The DMD™ accurately fills the width of the screen; however, the pillarboxing is now part of the projected image and is transferred to the screen.

The DMD™ does not fill the height of the screen, which has caused **letterboxing** - further blank spaces at the top and bottom of the screen.

The image is now surrounded by blank space, which can be removed if the throw ratio is increased.

Fig. 3 shows the image projected on the same screen with a lens chosen using TRC.

The increased throw ratio has allowed the 4:3 image to fill the 4:3 screen seamlessly.




Fig. 1




Fig. 2




Fig. 3

Notes



TRC can only be applied if greater than 1. If TRC is 1 or less, disregard it and calculate the throw ratio using the basic formula.

Calculating TRC

To calculate TRC, use the following formula:

$$TRC = \frac{1.78 \text{ (DMD™ aspect ratio)}}{\text{Source aspect ratio}}$$

TRC table

Alternatively, you can save time by referencing the following table, which shows the TRC value for some popular image formats:

2.35:1 (Scope) , 3840 x 1634 pixels	TRC < 1, not used
1.85:1 (Flat) , 3840 x 2075 pixels	TRC < 1, not used
1.78:1 (16:9) , 3840 x 2160	TRC < 1, not used (native resolution)
1.66:1 (Vista) , 3585 x 2160 pixels	TRC < 1.07, not used
1.6:1 (16:10) , 3456 x 2160 pixels	TRC = 1.11, not used
1.33:1 (4:3) , 2873 x 2160 pixels	TRC = 1.33
1.25:1 (5:4) , 2700 x 2160 pixels	TRC = 1.42

Notes



TRC can only be applied if greater than 1. If TRC is 1 or less, disregard it and calculate the throw ratio using the basic formula.

Calculating the throw ratio with TRC

- For TRC > 1, amend the basic throw ratio formula as follows:

$$\text{Throw ratio} = \frac{\text{Throw distance}}{\text{Screen width} \times \text{TRC}}$$

- Once a throw ratio is established, identify the matching lens from the table:

Throw ratios	Throw distance range
0.77 : 1 fixed lens	1.3 - 15 m (4.3 - 49.2 ft)
0.96 - 1.43 : 1 zoom lens	1.8 - 10.0 m (5.9 - 32.8 ft)
1.16 : 1 fixed lens	1.4 - 25 m (4.6 - 82 ft)
1.45 - 1.74 : 1 zoom lens	1.8 - 9.3 m (5.9 - 30.5 ft)
1.74 - 2.17 : 1 zoom lens	2.2 - 11.8 m (7.2 - 38.7 ft)
2.17 - 2.90 : 1 zoom lens	2.7 - 15.4 m (8.9 - 50.5 ft)
2.90 - 4.34 : 1 zoom lens	3.6 - 22.5 m (11.8 - 73.8 ft)
4.34 - 6.76 : 1 zoom lens	5.5 - 35 m (18 - 114.8 ft)

- Ensure the required throw distance is within the range of the matching lens.

Notes



TRC can only be applied if greater than 1. If TRC is 1 or less, disregard it and calculate the throw ratio using the basic formula.



Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.



For further information about using the right lens and hood, see [The lens hood](#) in the **Installation and Quick-Start Guide**.

Full lens calculation example

Your screen is **4.5 m** wide; you wish to place the projector approximately **11 m** from the screen. The source is **4:3**.

1. Calculate TRC as follows:

$$TRC = \frac{1.78}{1.33} = 1.33$$

2. Calculate the throw ratio:

$$Throw\ ratio = \frac{11}{4.5 \times 1.33} = 1.84$$

3. Find a match in the lens table.

The table shows that the matching lens is **the 1.74 - 2.17 : 1 zoom lens**.

4. Check whether the lens covers the required throw distance.

The range quoted for the 1.74 - 2.17 : 1 zoom lens is **2.2 - 11.8 m**. The required distance of 11 m is within the range.

INFORMATION YOU NEED FOR THESE CALCULATIONS

- The TRC formula $TRC = \frac{DMD^{TM}\ aspect\ ratio}{Source\ aspect\ ratio}$

- The TRC table (to use instead of the formula)

2.35:1 (Scope)	TRC not used
1.85:1 (Flat)	TRC not used
1.78:1 (16:9)	TRC not used (native resolution)
1.66:1 (Vista)	TRC = 1.07
1.6:1 (16:10)	TRC = 1.07
1.33:1 (4:3)	TRC = 1.33
1.25:1 (5:4)	TRC = 1.42

- The throw ratio formula $Throw\ ratio = \frac{Throw\ distance}{Screen\ width \times TRC}$

- The lens table:

Throw ratios	Throw distance range
0.77 : 1 fixed lens	1.3 - 15 m (4.3 - 49.2 ft)
0.96 - 1.43 : 1 zoom lens	1.8 - 10.0 m (5.9 - 32.8 ft)
1.16 : 1 fixed lens	1.4 - 25 m (4.6 - 82 ft)
1.45 - 1.74 : 1 zoom lens	1.8 - 9.3 m (5.9 - 30.5 ft)
1.74 - 2.17 : 1 zoom lens	2.2 - 11.8 m (7.2 - 38.7 ft)
2.17 - 2.90 : 1 zoom lens	2.7 - 15.4 m (8.9 - 50.5 ft)
2.90 - 4.34 : 1 zoom lens	3.6 - 22.5 m (11.8 - 73.8 ft)
4.34 - 6.76 : 1 zoom lens	5.5 - 35 m (18 - 114.8 ft)


Notes

Screen Requirements

Fitting the image to the display


If the source image supplied to the projector is smaller than the 4K-UHD resolution, the image will not fill the display. The following examples show how a number of common formats may be displayed, depending on your DMD™ resolution.

4K-UHD images displayed full width




Notes

4K-UHD images displayed with a height of 2160 pixels



Notes

4K-UHD images displayed full height



Notes

Diagonal screen sizes

Screen sizes are sometimes specified by their diagonal size (D). When dealing with large screens and projection distances at different aspect ratios, it is more convenient to measure screen width (W) and height (H).

The example calculations below show how to convert diagonal sizes into width and height, at various aspect ratios.

2.35:1 (Scope)

$W = D \times 0.92$ $H = D \times 0.39$

1.85:1

$W = D \times 0.88$ $H = D \times 0.47$

16:9 = 1.78:1 (native aspect ratio for 4K-UHD projectors)


$W = D \times 0.87$ $H = D \times 0.49$

1.66:1 (Vista)

$W = D \times 0.86$ $H = D \times 0.52$

16:10 = 1.6:1


$W = D \times 0.85$ $H = D \times 0.53$




Notes

Positioning The Image


The normal position for the projector is at the centre of the screen. However, you can set the projector above or below the centre, or to one side, and adjust the image using the **Lens shift** feature (known as **rising and falling front**) to maintain a geometrically correct image.



Shifting the lens up (rising front)





Centered lens



Shifting the lens down (falling front)


Notes

 For more information on shifting the lens, see [Lens control](#) in the [Operating Guide](#).


 Whenever possible, position the projector so that the lens is centered for the highest quality image.

Any single adjustment outside the ranges specified on the following page may result in an unacceptable level of distortion, particularly at the corners of the image, due to the image passing through the periphery of the lens optics.

If the lens is to be shifted in two directions combined, the maximum range without distortion will be somewhat less, as can be seen in the illustrations below.




Full horizontal or vertical shift



Combined shift is reduced

Notes

 For more information on shifting the lens, see [Lens control](#) in the **Operating Guide**.

Aspect Ratios Explained


The appearance of a projected image on the screen depends on a combination of the following:

- The display resolution is **4K-UHD** with a 3840 x 2160 resolution, corresponding to an aspect ratio of 16:9
- The aspect ratio of the input signal: usually **4:3**, **16:9** or **16:10**
- The value of the **Aspect Ratio** setting of the projector:
 - **16:9**, **4:3**, **16:10** and **5:4** stretch the image to the selected aspect ratio. **16:9** leaves black bars at the top and bottom of the screen (letterboxing effect); **4:3** and **5:4** leave black bars at the sides of the screen (pillarboxing).
 - **TheaterScope** is a special setting used in combination with an anamorphic lens, an optional accessory. It removes letterboxing from a 2.35:1 source packed into a 16:9 frame.
 - **4:3 Narrow** is a special setting used in combination with an anamorphic lens, an optional accessory. It squeezes 4:3 content so that the intended aspect ratio is displayed on screen when projected through an anamorphic lens.
 - **Source** shows the image with its original aspect ratio, if this does not match the native aspect ratio of the DMD™, then the image will be scaled to either fit the full width or height of the display.

Notes

Aspect ratio examples


Source: 4:3



Aspect Ratio: Source / 4:3

Aspect Ratio: 16:10


Source: 16:9



Aspect Ratio: Source / 16:9

Aspect Ratio: 16:10

Source: 16:10 (native)



Aspect Ratio: Source / 16:10


1 Unused screen areas

Notes


Aspect ratio example: TheaterScope

The **TheaterScope** setting is used in combination with an anamorphic lens to restore 2.35:1 images packed into a 16:9 frame. Such images are projected with black lines at the top and bottom of the 16:9 screen to make up for the difference in aspect ratios.


Without an anamorphic lens and without the TheaterScope setting applied, a 16:9 source containing a 2.35:1 image looks like this:



If we change the setting to **TheaterScope**, the black lines will disappear but the image will stretch vertically to reach the top and bottom of the DMD™:



An anamorphic lens will stretch the image horizontally, restoring the original 2.35 ratio:



Notes

Appendix A: Lens Part Numbers

Throw ratios	Part number	Throw distance range	Lens extension
0.77 : 1 fixed lens	110-808	1.3 - 15 m (4.3 - 49.2 ft)	170.9 mm
0.96 - 1.43 : 1 zoom lens	119-011	1.8 - 10.0 m (5.9 - 32.8 ft)	158.3 mm
1.16 : 1 fixed lens	110-809	1.4 - 25 m (4.6 - 82 ft)	144.3 mm
1.45 - 1.74 : 1 zoom lens	110-803	1.8 - 9.3 m (5.9 - 30.5 ft)	115.1 mm
1.74 - 2.17 : 1 zoom lens	112-878	2.2 - 11.8 m (7.2 - 38.7 ft)	73.7 mm
2.17 - 2.90 : 1 zoom lens	113-852	2.7 - 15.4 m (8.9 - 50.5 ft)	80.6 mm
2.90 - 4.34 : 1 zoom lens	110-806	3.6 - 22.5 m (11.8 - 73.8 ft)	72.6 mm
4.34 - 6.76 : 1 zoom lens	110-807	5.5 - 35 m (18 - 114.8 ft)	83.3 mm

Notes



The throw ratios given here apply only when the image fills the width of the DMD™.

For images that do not fill the width of the DMD™, the throw ratio needs to be recalculated using a throw ratio correction (TRC).

For further information, see [Choosing A Lens](#) and [Appendix B: Lens Charts](#).



Throw distance calculations are based on the distance from the outer end of the lens, which will vary from lens to lens.



Do not use the short lens hood with the 4.34 - 6.76 : 1 zoom lens.



For further information about using the right lens and hood, see [The lens hood](#) in the [Installation and Quick-Start Guide](#).

Appendix B: Supported Signal Input Modes

2D formats

Signal Format	Resolution	Frame Rate (Hz)	DisplayPort / DVI-D	HDMI / HD-BaseT				Output Frame Rate (Hz)	Remarks
				RGB	YUV 8-bit	YUV 10-bit	YUV 12-bit		
PC	640x480	59.94	X	X				60	
	640x480	74.99	X	X				60	
	640x480	85	X	X				60	
	800x600	60.32	X	X				60	
	800x600	75	X	X				60	
	800x600	85.06	X	X				60	
	848x480	47.95	X	X				48	
	848x480	59.94	X	X				60	
	1024*768	60	X	X				60	
	1024*768	75	X	X				60	
	1024*768	85	X	X				60	
	1280x720	47.95	X	X				48	
	1280x1024	60.02	X	X				60	
	1280x1024	75.02	X	X				60	
	1280x1024	85.02	X	X				60	
	1600x1200	60	X	X				60	
	1920x1080	47.95	X	X				48	
	1680x1050	59.94	X	X				60	
	1920x1200 RB	50	X	X				50	
	1920x1200 RB	60	X	X				60	
1400X1050	60	X	X				60		
1366 x 768	60	X	X				60		

Notes

Signal Format	Resolution	Frame Rate (Hz)	DisplayPort / DVI-D	HDMI / HD-BaseT				Output Frame Rate (Hz)	Remarks
				RGB	YUV 8-bit	YUV 10-bit	YUV 12-bit		
PC (continued)	1440 x 900	60	X	X				60	
	1280 x 768	60	X	X				60	
	1280 x 800	60	X	X				60	
	1280 x 960	60	X	X				60	
Apple Mac	640x480	66.59	X	X				60	
	832x624	74.54	X	X				60	
SDTV	480i	59.94						60	
	1440x480i	60		X	X	X	X	60	
	1440x576i	50		X	X	X	X	50	
	576i	50						50	
EDTV	480p	59.94	X	X	X	X	X	60	
	576p	50	X	X	X	X	X	50	
HDTV	1035i	60	X	X	X	X	X	60	
	1080i	50	X	X	X	X	X	50	
	1080i	59.94	X	X	X	X	X	60	
	1080i	60	X	X	X	X	X	60	
	720p	50	X	X	X	X	X	60	
	720p	59.94	X	X	X	X	X	60	
	720p	60	X	X	X	X	X	60	
	1080p	23.98	X	X	X	X	X	48	
	1080p	24	X	X	X	X	X	48	
	1080p	25	X	X	X	X	X	60	
	1080p	29.97	X	X	X	X	X	60	
	1080p	30	X	X	X	X	X	60	
	1080p	50	X	X	X	X	X	50	

Notes

Signal Format	Resolution	Frame Rate (Hz)	DisplayPort / DVI-D	HDMI / HD-BaseT				Output Frame Rate (Hz)	Remarks
				RGB	YUV 8-bit	YUV 10-bit	YUV 12-bit		
HDTV (continued)	1080p	59.94	X	X	X	X	X	60	
	1080p	60	X	X	X	X	X	60	
	2K (2048x1080)	24/25/30/50/60	X	X	X	X	X	48/50/60/50/60	
	4K-UHD	24/25/30	X	X	X	X*1	X*1	48/50/60	*1
	4K-UHD	50/60	X	X (8 bits)	X*2	X*3	X*3	50/60	*2, *3

SDI Format

Timing	SDI Link mode	Signal Standards	Color Encode	Sampling Structure	Bit Depth
NTSC	SD	SMPTE 259M-C 270Mbps SD	YCbCr	4:2:2	10
PAL	SD	SMPTE 259M-C 270Mbps SD	YCbCr	4:2:2	10
1035i60	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080i59	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080i60	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080P30	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080P25	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080i50	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080P24	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
720P60	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
720P50	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080Sf25	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080Sf30	HD	SMPTE 292M 1.5Gbps HD	YCbCr	4:2:2	10
1080P50	3G Level A	SMPTE 424M 3Gbps	YCbCr	4:2:2	10

Notes



Remarks:

*1 HDBaseT supports 4K 24/25/30Hz 4:2:2 only

*2 HDBaseT supports 4K 50/60Hz 4:2:0 only

*3 HDMI 1,2 support up to 4:2:2, HDBaseT does not support

Timing	SDI Link mode	Signal Standards	Color Encode	Sampling Structure	Bit Depth
1080P59	3G Level A	SMPTE 424M 3Gbps	YCbCr	4:2:2	10
1080P60	3G Level A	SMPTE 424M 3Gbps	YCbCr	4:2:2	10
1080P50	3G Level B	SMPTE 424M 3Gbps	YCbCr	4:2:2	10
1080P59	3G Level B	SMPTE 424M 3Gbps	YCbCr	4:2:2	10
1080P60	3G Level B	SMPTE 424M 3Gbps	YCbCr	4:2:2	10

Appendix C: Wiring Details

Signal inputs and outputs

HDMI 1 and 2

19 way type A connector

- 1 TMDS Data 2+
- 2 TMDS Data 2 Shield
- 3 TMDS Data 2-
- 4 TMDS Data 1+
- 5 TMDS Data 1 Shield
- 6 TMDS Data 1-
- 7 TMDS Data 0+
- 8 TMDS Data 0 Shield
- 9 TMDS Data 0-
- 10 TMDS Clock+
- 11 TMDS Clock Shield
- 12 TMDS Clock-
- 13 CEC
- 14 not connected
- 15 SCL (DDC Clock)
- 16 SCA (DDC Data)
- 17 DDC/CEC Ground
- 18 +5 V Power
- 19 Hot Plug Detect




HDMI: pin view of panel connector

Notes

DisplayPort

DisplayPort 1.2

Pin 1	ML_Lane 0 (p)	Lane 0 (positive)
Pin 2	GND	Ground
Pin 3	ML_Lane 0 (n)	Lane 0 (negative)
Pin 4	ML_Lane 1 (p)	Lane 1 (positive)
Pin 5	GND	Ground
Pin 6	ML_Lane 1 (n)	Lane 1 (negative)
Pin 7	ML_Lane 2 (p)	Lane 2 (positive)
Pin 8	GND	Ground
Pin 9	ML_Lane 2 (n)	Lane 2 (negative)
Pin 10	ML_Lane 3 (p)	Lane 3 (positive)
Pin 11	GND	Ground
Pin 12	ML_Lane 3 (n)	Lane 3 (negative)
Pin 13	CONFIG1	connected to Ground1)
Pin 14	CONFIG2	connected to Ground1)
Pin 15	AUX CH (p)	Auxiliary Channel (positive)
Pin 16	GND	Ground
Pin 17	AUX CH (n)	Auxiliary Channel (negative)
Pin 18	Hot Plug	Hot Plug Detect
Pin 19	Return	Return for Power
Pin 20	DP_PWR	Power for connector (3.3 V 500 mA)



DisplayPort: pin view of panel connector

Notes

3G-SDI In, 3G-SDI Out


75 ohm BNC



3G-SDI connector

HDBaseT input

RJ45 socket.



HDBaseT input

Notes



3G-SDI signals are very high speed digital signals which require better quality coaxial cable than conventional analogue video. The data rate is 3 Gigabits per second.


In choosing cable length and connectors for any installation the frequency response loss in decibels should be proportional to \sqrt{f} , from 1 MHz, to 3 GHz.

Control connections

LAN

RJ45 socket

(Shared with HDBaseT)




HDBaseT/LAN port

RS232

9 way D-type connector

- 1 unused
- 2 Received Data (RX)
- 3 Transmitted Data (TX)
- 4 unused
- 5 Signal Ground
- 6 unused
- 7 unused
- 8 unused
- 9 unused



RS232:
pin view of female connector

Notes



Only one remote connection (RS232 or LAN) should be used at any one time.


Trigger 1 & Trigger 2

3.5 mm mini jack

Tip Signal

Sleeve Ground

Output: 12V, 200 mA max




IR input

3.5 mm mini jack

Tip Signal

Ring Not connected

Sleeve Ground



Notes

Appendix D: Glossary Of Terms

1080p

An [HDTV resolution](#) which corresponds to 1920 x 1080 [pixels](#) (a widescreen [aspect ratio](#) of 16:9).

3D active glasses

Wireless battery-powered glasses with LCD shutters. Synchronization information is communicated to the glasses by means of an infrared (IR) or radio frequency (RF) emitter which is connected to the Sync Out terminal on the projector. IR or RF pulses are transmitted by the emitter to signal when the left eye and right eye images are being displayed. The glasses incorporate a sensor which detects the emitter's signal and synchronises the left and right eye shutters with the projected image.

4K-UHD

An [HDTV resolution](#) which corresponds to 3840 x 2160 [pixels](#) (a widescreen [aspect ratio](#) of 16:9).

Adjust lines

A pattern applied to the image where its edge is to be blended with another image. Adjust lines are used to position the projectors in the array during the [edge blend](#) process.

Anamorphic lens

A special lens which, when used with the [TheaterScope aspect ratio](#), allows watching 2.35:1 content packed in a 16:9 source.

Aperture

The opening of the lens that determines the angle through which light travels to come into focus.

Aspect ratio

The proportional relationship between the width and the height of the projected image. It is represented by two numbers separated by a colon, indicating the ratio of image width and height respectively: for example, 16:9 or 2.35:1.

Not to be confused with [resolution](#).

Notes

Blanking (projection)

The ability to intentionally turn off, that is, set to black, areas around the edges of the projected image. It is sometimes referred to as “curtains” since it can be used to blank an area of image that literally falls on the curtains at the side of the screen in a movie theater. Usually no image resizing or geometric correction takes place and the “blanked” part of the image is lost.

Not to be confused with horizontal and vertical [blanking \(video signal\)](#).

Blanking (video signal)

The section of the video signal where there is no active video data.

Not to be confused with [blanking \(projection\)](#).

Blend region

The area of the image that is to overlap with another image in an [edge blend](#) setup. Sometimes called *overlapping region*.

Brightness (electronic control)

A control which adds a fixed intensity value to every [pixel](#) in the display, moving the entire range of displayed intensities up or down, and is used to set the black point in the image (see [Contrast](#)). In [Component Video](#) signals, brightness is the same as [luminance](#).

Brightness (optical)

Describes how ‘bright’ an image that is projected onto a screen appears to an observer.

C

See [Chrominance](#).

Chrominance

Also known as ‘[C](#)’, this is the component, or pair of components, of a [Component Video](#) signal which describes [color difference](#) information.

Color difference

In [Component Video](#) signals, the difference between specified colors and the [luminance](#) component. Color difference is zero for monochrome images.

Notes

Color gamut

The spectrum of color available to be displayed.

Color temperature

The position along the black body curve on the chromaticity diagram, normally quoted in Kelvin. It takes into account the preset values for color balance in the service set-up to take up the variations in the prism. The projector allows you to adjust this temperature (i.e. adjust the picture color temperature).

Component video

A three-wire or four-wire video interface that carries the signal split into its basic **RGB** components or **luminance (brightness)** and two-**color-difference** signals (**YUV**) and **synchronization** signals.

Contrast (electronic control)

The adjustment of the white point of the image without affecting the black point. This increases the intensity range of the displayed image.

Contrast (optical)

The intensity difference between the darkest and lightest areas of the screen.

Cr, Cb

Color difference signals used with 'Y' for digital **Component Video** inputs. They provide information about the signal color. Not to be confused with **Pr, Pb**.

Crop

Remove part of the projected image.

Alternatively, fit an image into a frame with a different **aspect ratio** by removing part of the image. The image is resized so that either its length or its width equals the length or width of the frame, while the other dimension has moved outside the frame; the excess area is then cut out.

Notes

Dark time

The time inserted between [frames](#) when using [3D active glasses](#), to avoid [ghosting](#) caused by switching time between left and right eye.

DDC (Display Data Channel)

A communications link between the source and projector. DDC is used on the HDMI, DVI and VGA inputs. The link is used by the source to read the [EDID](#) stored in the projector.

Deinterlacing

The process of converting [interlaced](#) video signals into [progressive](#) ones.

DHCP (Dynamic Host Configuration Protocol)

A network protocol that is used to configure network devices so that they can communicate on an IP network, for example by allocating an IP address.

DMD™ (Digital Micromirror Device™)

The optical tool that transforms the electronic signal from the input source into an optical image projected on the screen. The DMD™ of a projector has a fixed [resolution](#), which affects the [aspect ratio](#) of the projected image.

A Digital Micromirror Device™ (DMD™) consists of moving microscopic mirrors. Each mirror, which acts as a [pixel](#), is suspended between two posts by a thin torsion hinge. It can be tilted to produce either a bright or dark pixel.

Edge blend

A method of creating a combined image by blending the adjoining edges of two or more individual images.

Edge tear

An artifact observed in [interlaced video](#) where the screen appears to be split horizontally. Edge tears appear when the video feed is out of sync with the refresh rate of the display device.

Notes

EDID (Extended Display Identification Data)

Information stored in the projector that can be read by the source.

EDID is used on the HDMI, DVI and VGA inputs, allowing the source to automatically configure to the optimum display settings.

EDTV (Enhanced Definition Television)

A [progressive](#) digital television system with a lower resolution than [HDTV](#).

Field

In [interlaced video](#), a part of the image [frame](#) that is scanned separately. A field is a collection of either all the odd lines or all the even lines within the frame.

Frame

One of the many still images displayed in a sequence to create a moving picture. A frame is made of horizontal lines of [pixels](#). For example, a 1920x1080 frame consists of 1080 lines, each containing 1920 pixels. In analog video frames are scanned one at a time ([progressive scanning](#)) or split into [fields](#) for each field to be scanned separately ([interlaced video](#)).

Frame rate

The number of [frames](#) shown per second (fps). In TV and video, a frame rate is the rate at which the display device scans the screen to “draw” the frame.

Frame rate multiplication

To stop low [frame rate](#) 3D images from flickering, frame rate multiplication can be used, which increases the displayed frame rate by two or three times.

Gamma

A nonlinear operation used to code and decode [luminance](#). It originates from the Cathode Ray Tube technology used in legacy television sets.

Notes

Ghosting

An artifact in 3D image viewing. Ghosting occurs when an image intended for one eye is partially seen by the other eye.

Ghosting can be removed by optimizing the [dark time](#) and sync delay.

HDCP (High-bandwidth Digital Content Protection)

An encryption scheme used to protect video content.

HDTV (High Definition Television)

A television system with a higher [resolution](#) than [SDTV](#) and [EDTV](#). It can be transmitted in various formats, notably [1080p](#) and 720p.

Hertz (Hz)

Cycles per second.

Horizontal Scan Rate

The rate at which the lines of the incoming signal are refreshed. The rate is set by the horizontal [synchronization](#) from the source and measured in [Hertz](#).

Hs + Vs

Horizontal and vertical [synchronization](#).

Hue

The gradation (red/green balance) of color (applicable to [NTSC](#)).

Interlacing

A method of updating the image. The screen is divided in two [fields](#), one containing every odd horizontal line, the other one containing the even lines. The fields are then alternately updated. In analog TV interlacing was commonly used as a way of doubling the refresh rate without consuming extra bandwidth.

Notes

Interleaving

The alternation between left and right eye images when displaying 3D.

LED (Light Emitting Diode)

An electronic component that emits light.

Letterboxing

Black margins at the top and bottom of the image. Letterboxing appears when a wider image is packed into a narrower [frame](#) without changing the original [aspect ratio](#).

Lumen

A photometric unit of radiant power. For projectors, it is normally used to specify the total amount of emitted visible light.

Luminance

Also known as '[Y](#)', this is the part of a [Component Video](#) signal which affects the brightness, i.e. the black and white part.

Noise

Electrical interference displayed on the screen.

NTSC (National Television Standards Committee)

The United States standard for television - 525 lines transmitted at 60 [interlaced fields](#) per second.

OSD (on-screen display)

The projector menus allowing you to adjust various settings.

Overlapping region

See [blend region](#).

Notes

PAL (Phase Alternate Line)

The television system used in the UK, Australia and other countries - 625 lines transmitted at 50 [interlaced fields](#) per second.

Pillarboxing

Black margins at the left and right of the image. Pillarboxing appears when a narrower image is packed into a wider [frame](#) without changing the [aspect ratio](#).

Pixel

Short for *Picture Element*. The most basic unit of an image. Pixels are arranged in lines and columns. Each pixel corresponds to a micromirror within the [DMD™](#); resolutions reflect the number of pixels per line by the number of lines. For example, a [1080p](#) projector contains 1080 lines, each consisting of 1920 pixels.

Pond of mirrors

Area around the periphery of the [DMD™](#) containing inactive mirrors. The pond of mirrors may cause artifacts, for example during the [edge blending](#) process.

Pr, Pb

[Color difference](#) signals used with 'Y' for analog [Component Video](#) inputs. They provide information about the signal color. Not to be confused with [Cr, Cb](#).

Primary colors

Three colors any two of which cannot be mixed to produce the third. In additive color television systems the primary colors are red, green and blue.

Progressive scanning

A method of updating the image in which the lines of each [frame](#) are drawn in a sequence, without [interlacing](#).

Pulldown

The process of converting a 24 fps film footage to a video [frame rate](#) (25 fps for [PAL/SECAM](#), 30 fps for [NTSC](#)) by adding extra [frames](#). DP projectors automatically carry out reverse pulldown whenever possible.

Notes

Resolution

The number of [pixels](#) in an image, usually represented by the number of pixels per line and the number of lines (for example, 1920 x 1200).

RGB (Red, Green and Blue)

An uncompressed [Component Video](#) standard.

Saturation

The amount of color in an image.

Scope

An [aspect ratio](#) of 2.35:1.

SDTV (Standard Definition Television)

An [interlaced](#) television system with a lower [resolution](#) than [HDTV](#). For [PAL](#) and [SECAM](#) signals, the resolution is 576i; for [NTSC](#) it is 480i.

SECAM (Sequential Color with Memory)

The television system used in France, Russia and some other countries - 625 lines transmitted at 50 [interlaced fields](#) per second.

SX+

A display [resolution](#) of 1400 x 1050 pixels with a 4:3 screen [aspect ratio](#). (Shortened from SXGA+, stands for *Super Extended Graphics Array Plus*.)

Synchronization

A timing signal used to coordinate an action.

Test pattern

A still image specially prepared for testing a projection system. It may contain various combinations of colors, lines and geometric shapes.

Notes

TheaterScope

An [aspect ratio](#) used in conjunction with a special [anamorphic lens](#) to display 2.35:1 images packed into a 16:9 [frame](#).

Throw distance

The distance between the screen and the projector.

Throw ratio

The ratio of the [throw distance](#) to the screen width.

TRC (Throw ratio correction)

A special number used in calculating [throw distances](#) and [throw ratios](#) when the image does not fill the width of the [DMD™](#).

TRC is the ratio of the [DMD™ aspect ratio](#) to the image source aspect ratio:

$$TRC = \frac{DMD^{\text{TM}} \text{ aspect ratio}}{\text{Source aspect ratio}}$$

TRC is only used in calculations if it is greater than 1.

UXGA

A display [resolution](#) of 1600 x 1200 [pixels](#) with a 4:3 screen [aspect ratio](#). (Stands for *Ultra Extended Graphics Array*.)

Vertical Scan Rate

The rate at which the [frames](#) of the incoming signal are refreshed. The rate is set by the vertical [synchronization](#) from the source and measured in [Hertz](#).

Vignetting

Optical cropping of the image caused by the components in the projection lens. This can happen if too much offset is applied when positioning the image using the lens mount.

Notes

Vista

An [aspect ratio](#) of 1.66:1.

WUXGA

A display [resolution](#) of 1920 x 1200 [pixels](#) with a 16:10 screen [aspect ratio](#). (Stands for Widescreen *Ultra Extended Graphics Array*.)

Y

This is the [luminance](#) input ([brightness](#)) from a [Component Video](#) signal.

YUV

See [Pr](#), [Pb](#).

ZScreen

A special kind of light modulator which polarizes the projected image for 3D viewing. It normally requires that images are projected onto a silver screen. The ZScreen is placed between the projector lens and screen. It changes the polarization of the projected light and switches between left- and right-handed circularly polarized light at the field rate.

Notes



Contact Information:

Digital Projection Limited

Greenside Way, Middleton
Manchester M24 1XX, UK

*Registered in England No. 2207264
Registered Office: as above*

Tel (+44) 161 947 3300
Fax (+44) 161 684 7674

enquiries@digitalprojection.co.uk
service@digitalprojection.co.uk

www.digitalprojection.co.uk

Digital Projection Inc.

55 Chastain Road, Suite 115
Kennesaw, GA 30144, USA

Tel (+1) 770 420 1350
Fax (+1) 770 420 1360

powerinfo@digitalprojection.com
www.digitalprojection.com

Digital Projection China

中国 北京市 朝阳区 芍药居北里101号
世奥国际中心A座2011室(100029)

Rm A2011
ShaoYaoJu 101 North Lane
Shi Ao International Center
Chaoyang District
Beijing 100029, PR CHINA

Tel (+86) 10 84888566
Fax (+86) 10 84888566-805

techsupport@dp-china.com.cn
www.dp-china.com.cn

Digital Projection Asia

16 New Industrial Road
#02-10 Hudson Technocentre
Singapore 536204

Tel (+65) 6284-1138
Fax (+65) 6284-1238

www.digitalprojectionasia.com